

MARKIII+ Electric Fire Pump Controller - Wye-Delta Closed Transition Starting With Power Transfer Switch

**Project Information** 

VOLTAGE/POWER TABLE				
LINE VOLTAGE	MOTOR HORSEPOWER			
380-400-415	150-200			
440-480	200-250			
600	250-350			
APPROX SHIPPING WT: 850 [386]				

DRAWINGS INCLUDED IN THIS PACKAGE ARE FOR STANDARD CONTROLLERS. ACTUAL "AS BUILT" DRAWINGS MAY DIFFER FROM THOSE SHOWN HERE.

## Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com

While every precaution has been taken to ensure accuracy and completeness herein, Firetrol, Inc. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications and drawings are subject to change without notice. ©2023 Firetrol, Inc., All Rights Reserved.

## Firetrol Mark" Electric Fire Pump Controller

FTA1350/FTA950 - Wye-Delta Closed Transition Starting with Power Transfer Switch Specifications

## 1.0 Main Fire Pump Controller

The main fire pump controller shall be a factory assembled, wired and tested unit. The controller shall be of the combined manual and automatic type designed for full voltage starting of the fire pump motor having the horsepower, voltage, phase and frequency rating shown on the plans and drawings. The controller shall be rated for an Ambient Temperature Operating Range of 39°F (4°C) to 104°F (40°C).

## 1.1 Standards, Listings & Approvals

The controller shall conform to all the requirements of the latest editions of: NFPA 20, Standard for the Installation of Stationary Pumps for Fire Protection NFPA 70, National Electrical Code.

The controller shall be listed by:

Underwriters Laboratories, Inc., in accordance with UL218, Standard for Fire Pump Controllers Canadian Standards Association CSA-C22.2, Standard for Industrial Control Equipment (cUL)

CE - Low Voltage Directive

The controller shall be approved by:

Factory Mutual (IEC 62091)

The City of New York for fire pump service

## 1.2 Enclosure

The controller components shall be housed in a NEMA Type 2 (IEC IP22) drip-proof, wall mounted enclosure.

## 1.3 Withstand Ratings (Short Circuit Current Ratings)

All controller components shall be front mounted, wired and front accessible for maintenance. The available short circuit current ratings are shown below. The ratings shall apply to the normal and emergency power components.

Code	200-208V 2		220-240V 3		-415V	440-480		550-600	
	5-150 HP	5	-200 HP	5-3	50 HP	5-400	ΗP	5-500 HP	
M - Standard	100kA		100kA	10	0kA	100kA		N/A	
N - Intermediate	150kA		150kA	15	0kA	150k <i>A</i>	4	N/A	
P - High	200kA		200kA	20	0kA	200k	4	N/A	
Q - Intermediate	N/A		N/A	N	I/A	N/A		100kA	
R - Standard	N/A		N/A	N	I/A	N/A		50kA	
	200-208V	/	220-24	.0V	380-	-415V	2	440-480	
Code	200 HP		250-400 HP		400-	500 HP	45	50-500 HP	
M - Standard	50A		50kA		50	50kA		50kA	
N - Intermediate	N/A		N/A		N/A		N/A		
P - High	100kA		100kA		100kA			100kA	
Q - Intermediate	N/A		N/A		N/A			N/A	
R - Standard	N/A		N/A		N/A			N/A	

## 1.4 Power Components

The controller shall include a combination isolating disconnect switch/circuit breaker, rated for not less than 115% of the motor full load current, mechanically interlocked and operated with a single, externally mounted handle. The isolating disconnect switch/ circuit breaker shall be mechanically interlocked so that the enclosure door cannot be opened with the handle in the ON position except by a hidden tool operated bypass mechanism. The isolating disconnect switch/circuit breaker shall be capable of being padlocked in the OFF position for installation and maintenance safety, and shall also be capable of being locked in the ON position without affecting the tripping characteristics of the circuit breaker.

The controller will include a voltage surge arrestor and Wye-Delta Closed Transition motor starter.

The controller shall be equipped with a single handle, manually operated, emergency start mechanism capable of being latched in the ON position.

The controller shall include an Automatic Transfer Switch, electrically or manually operated, mechanically held.

## 1.5 Operator Interface (HMI)

The operator interface shall be a 7.0" LCD capacitive type color touch screen (HMI technology) powered by an embedded microcomputer with software PLC logic. Included shall be keypad type push-buttons for START, STOP, RUN TEST and TRANSFER SWITCH TEST.

The screen shall include menus for: Home · Alarms · Configuration · History · Service · Manuals · Language.

The HMI shall graphically display the following: Voltage and Amperage of all 3 phases simultaneously using true RMS Technology for both the Normal and Alternate Power Sources · Transfer Switch Status · Motor Stopped/Running · Starting Cause · Actuation Mode · Controller Type · Shutdown Mode · Date & Time · Pump Room Temp. · System Pressure

System pressure shall be capable of being displayed as: PSI, kPa, Bar, Feet of Head or Meters of Water.

The HMI shall allow programming and display of: Cut In & Cut Out Pressure Settings · Minimum Run Timer · Sequential Start Timer · Periodic Test Timer

The HMI allows the user to select the language of the system and download the manual or view the manual on screen.

## 1.6 State and Alarm Indication

Visual indication shall be provided for the following:

Power Available • Motor Run • Periodic Test • Manual Start • Deluge Valve Start • Remote Automatic Start • Remote Manual Start • Emergency Start • Pump On Demand/Automatic Start • Pump Room Temperature • Lockout

The digital display shall visually indicate the following alarms:

Alternate Power Lock Rotor Current • Alternate Power Phase Reversal • Automatic Power Transfer Switch Trouble • Locked Rotor Current • Fail To Start • Under/Over Current • Under/Over Voltage • Phase Unbalance • Check Test Solenoid Valve • Weekly Test Cut-In Not Reached • Transducer Fault • Control Voltage Not Healthy • Motor Trouble • Pump Room Alarm • Invalid Cut-In • Phase Reversal • Power Loss • Phase Loss L1 / L2 / L3 • Low Water Level • Pump On Demand • Low Ambient Temp. • Service Required

Audible and visible alarm shall be provided for:

Fail To Start • Alternate Circuit Breaker Off or Tripped • Alternate Isolating Switch Tripped/ Open •

Remote Alarm contacts shall be provided for:

Power Available • Phase Reversal • Motor Run • Common Pump Room Alarm (Overvoltage, Undervoltage, Phase Unbalance, Low/High Pump Room Temperature) • Common Motor Trouble (Overcurrent, Fail To Start, Undercurrent, Ground Fault) • Transfer Switch in Normal Position • Transfer Switch in Alternate Position • Alternate Power Isolating Switch Off

## 1.7 Pressure and Event Recording

The system shall be capable of logging pressure data and operational events with time/date stamp. The system shall display operational events for the lifetime of the controller and display the pressure data in text or graphical form. The controller shall log the Date/Time of the first start-up and the controller total power on time from that date. The controller shall log first and last statistics for: First Setup · On Time · Start Count · Last Start Time · Min/Max/Average System Pressure · Min/Max/Average Pump Room Temp. · Jockey Pump On Time/Start Count/Last Start Time · Phase to Phase Voltages with Date Stamp · Amps Per Phase with Date Stamp

## 1.8 USB Host Controller

A USB port capable of accepting a USB Flash Memory Disk shall be provided for downloading pressure and event logs.

## 1.9 Serial Communications

The controller shall feature Modbus with TCP/IP frame format and shielded female RJ45 connector

## 2.0 Pressure Sensing / Wet Parts

The controller shall be supplied with a solid state pressure transducer with a range of 0-500 psi calibrated for 0-300 psi (0-20.7 bar) and a run test solenoid valve. The wet parts shall be externally mounted and include a protective cover. The pressure sensing line connection to the transducer shall be 1/2-inch FNPT. Provisions for a redundant pressure transducer shall be provided.

## 2.1 Controller Operation

The controller shall be capable of automatic starting via pressure drop, remote start signal from an automatic device or a deluge valve. The controller can be manually started via the START push-button, the RUN TEST push-button, or a remote signal from a manual device. Stopping can be achieved manually with the STOP push-button or automatically after expiration of minimum run timer or test timer. The minimum run timer (off delay), sequential start timer (on delay) and periodic test timer shall be field adjustable and include a visual countdown on the display. Adjustable timers shall be supplied for Momentary Normal Power Outage Override, Alternate Power Available Delay, Transfer Trouble Delay, Retransfer To Normal, Generator Cooldown.

#### 2.2 Manufacturer

The controller shall be a Firetrol brand.



MARKIII+ Electric Fire Pump Controllers - Wye-Delta Closed Transition Starting with Power Transfer Switch



Description—Firetrol® FTA1350 Wye-Delta, Closed Transition Starting Fire Pump Controllers are used with delta-wound squirrel cage motors. FTA1350 controllers are of the closed circuit transition type in which the motor circuit remains closed during the transition from start to run. The controller monitors, displays and records fire pump system information. Actuating the controller via pressure, START push-button or deluge valve contact closes the start contactor connecting the motor to the line in the wye connection. The motor will draw approximately 33% of its normal inrush current and develop approximately 33% of its normal starting torque. After a time delay, the motor is automatically reconnected in delta, applying full voltage to the motor windings. During this transition, a resistor is connected to each phase, minimizing line disturbances and voltage drop during starting. These controllers are recommended especially for use with generator sets.

Power Transfer Switches are completely assembled with Firetrol Electric Fire Pump Controllers; full or reduced voltage types. The power transfer switches are built for use with generator set or 2nd utility use. The entire package of power transfer switch and controller is completely

factory assembled, wired, tested and shipped as a complete unit for easy field connection to the power sources and the fire pump motor.

Approvals – Firetrol fire pump controllers are listed by Underwriters' Laboratories, Inc., in accordance with UL218, Standard for Fire Pump Controllers, CSA, Standard for Industrial Control Equipment, and approved by Factory Mutual. They are built to meet or exceed the requirements of the approving authorities as well as NEMA and the latest editions of NFPA 20, Installation of Centrifugal Fire Pumps, and NFPA 70, National Electrical Code.

The power transfer switches are listed by Underwriters' Laboratories, Inc., in accordance with UL218, Standard for Fire Pump Controllers; UL1008, Automatic Transfer Switches; UL508, Industrial Control Equipment, CSA, Standard for Industrial Control Equipment, and approved by Factory Mutual. They are built to meet or exceed the requirements of the approving authorities as well as NEMA and the latest editions of NFPA 20, Installation of Centrifugal Fire Pumps, and NFPA 70, National Electrical Code.

Controller Standard Features — The following are included as standard with each controller:

- Voltage surge protector
- Main Disconnect Switch sized for connected motor horsepower and voltage
- Fire pump Circuit Breaker
- Single Handle Isolating Disconnect Switch/Circuit Breaker mechanism
- Motor contactor

 Single Handle Emergency Manual Run Mechanism to mechanically close motor contactor contacts in an emergency condition

 Built-in Start and Stop push-buttons to bypass automatic start circuits

Daylight Savings Time Option

Elapsed Time Meter

 7.0" LCD capacitive type color touch screen (HMI technology) software upgradeable operator interface powered by an embedded microcomputer with software PLC logic.

 500 PSI Pressure Transducer (calibrated for 300 PSI (20.7 Bar))and Test Solenoid for fresh water applications, externally mounted with protective

cover

 Audible alarm buzzer embedded in the MarkIII+

• Pump Room Ambient Temperature

Switch, Display and Alarms

- Pressure and Event Recording with Date Stamp to System Memory Accessible VIA The User Interface and Downloadable to a USB Flash Drive
- Modbus Communications with TCP/IP frame format and a shielded female RJ45 connector
- NEMA Type 2 (IEC IP22) enclosure with bottom entry gland plate and lifting lugs
- Suitable for use as Service Equipment
- The controller supplies visual indication of the following: Power Available
   Motor Run Periodic Test Manual Start Deluge Valve Start Remote Automatic Start Remote Manual Start Emergency Start Pump On Demand (Automatic Start) Pump Room Temp. Lockout
- The controller displays visual indication for the following alarm conditions:
   Control Voltage Not Healthy Invalid Cut-In Lock Rotor Current Loss of Power Low Ambient Temp. Low Water Level Motor Trouble Phase Reversal Overcurrent Overvoltage Phase Loss L1 / L2 / L3 Phase Unbalanced Pressure Transducer Fault Detected Pump On Demand Pump Room Alarm

- Service Required Undercurrent Undervoltage • Check Test Solenoid • Weekly Test Cut-In Reached
- Audible and Visible Indication for Fail To Start.
- DPDT 8A, 250VAC remote alarm contacts are provided for: Power Available
   Phase Reversal Motor Run
  - Common Pump Room Alarm (Overvoltage / Undervoltage / Phase Unbalance / Low Pump Room Temp. / High Pump Room Temp)

 Common Motor Trouble (Overcurrent / Fail To Start / Undercurrent / Ground

Fault)

 Field Adjustable Timers with Visual Countdown for Minimum Run (Off Delay), Sequential Start (On Delay) and Weekly Test

## **Transfer Switch Standard Features** – The following are included as standard with each controller:

- Visual indication of the following: Alternate Power Lock Rotor Current Alternate Power Phase Reversal Automatic Transfer Switch Trouble
- Audible and Visible indication of: Alternate Power Circuit Breaker OFF or Tripped • Alternate Power Isolating Switch Tripped/Open
- Transfer Switch test push-button
- Bypass for re-transfer and generator shutdown
- The following adjustable time delays are provided:
  - Momentary Normal Power Outage Override • Emergency Power Available Delay • Transfer Trouble Delay • Re-transfer to Normal • Generator Cooldown
- Remote Alarm Contacts For: Emergency Isolating Switch Off • Transfer Switch in Normal Position • Transfer Switch in Emergency Position


FOR MODEL # INFORMATION SEE PUBLICATION SD1000-61 FOR OPTIONS AND MODIFICATIONS SEE PUBLICATION OP1000-72

## Firetrol, Inc.


3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com




## MARKIII+ Electric Fire Pump Controllers - Wye-Delta Closed Transition Starting



## **General Starting Configuration**






Legend:

FLA: Full Load Amperage / Full Load Current

FLT: Full-Load Torque / Rated Torque at FLA, Vn, and Full-Load Speed

Vn : Nominal Voltage / Rated Voltage DOL : Direct On Line / Across-The-Line



**Starting Method:** Wye-Delta closed transition **Starting voltage per winding:** Reduced

Typical voltage applied at motor starting (%Vn): 100%

Peak inrush current at starting (1): 3.5 - 9 x FLA Peak inrush current at transition (1): Negligible Starting current (% FLA) (2): 165 - 330% Transition current (% FLA) (3): 165 - 330%

Starting Torque (% FLT) (4): 20 - 50% Motor type: Standard Wye-Delta Number of wire connections: 6

- 1) A transient peak occurs when starting the motor while at rest or when disconnecting and reconnecting the motor during a transition. This transient lasts no more than 1/2 cycle.
- 2) The starting current (locked rotor current) is the Root Mean Square current value the motor takes from the power source at start and fades while the motor is accelerating to full speed. The larger the load on the motor, the slower the acceleration and the higher the current.
- 3) The transition current depends on the moment the transition occurs and the speed of the motor. A early transition will lead to increased current as the motor has not reached full speed for the load and voltage. A late transition suggests that the motor will be running at reduced voltage when the load is almost the same as full load. This causes the motor efficiency to drop and the temperature to rise in the motor stator windings. The motor can withstand this for a short period of time but it is not recommended to run the motor with reduced voltage for more than 5 seconds.
- 4) Generally, the torque developed by the induction motor at any speed is approximately proportional to the square of the voltage and inversely proportional to the square of the frequency. The locked rotor torque and breakdown torque are decreased when the voltage is unbalanced. If the voltage imbalance is severe, the torque may be inadequate for the application.
- 5) Induction motors are inherently capable of developing transient current and torque considerably in excess of rated current and torque when exposed to an out of phase bus transfer or momentary voltage interruption and re-closing on the same power supply. This transient torque can range from 2 to 20 times the rated torque and is related to many factors including: motor design, operating conditions, switching time, rotating system inertias and torsional spring constants, the number of motors on the bus and more.

This information is provided as a general information document. Consult an electrical engineer on your specific application.

## Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com

While every precaution has been taken to ensure accuracy and completeness herein, Firetrol, Inc. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications and drawings are subject to change without notice. ©2021 Firetrol, Inc., All Rights Reserved.

## MARKIII+ Electric Fire Pump Controllers with Power Transfer Switch

## FTA1000, 1250, 1300, 1350, 1800, 1930 ELECTRIC FIRE PUMP CONTROLLERS

Example: FTA1300-AM75HH-TSA-xx

### Starting Method

1000 - Across-the-line (direct on line)

1250 - Part Winding (50%-50% windings)

1300 - Wye-delta (star-delta), open transition

1350 - Wye-delta (star-delta), closed transition

1800 - Autotransformer

1930 - Digital Solid-state soft start/stop

## Start/Stop Options

- A Automatic/Manual start with manual stop only (default). Field configurable to automatic start with timed permissive stop after minimum run time and manual start with manual stop only.
- C For Manual only operation of Foam Controllers (use option -LK3)

				l .		l .		
Code	200-208V	2	20-240V	380	-415V	440-48	80V	550-600V
	5-150 HP	5	5-200 HP	5-3	50 HP	5-400	ΗP	5-500 HP
M - Standard	100kA		100kA	10	0kA	100kA		N/A
N - Intermediate	150kA		150kA	15	0kA	150kA		N/A
P - High	200kA		200kA	20	0kA	200kA		N/A
Q - Intermediate	N/A		N/A	N	I/A	N/A		100kA
R - Standard	Standard N/A		N/A	N/A		N/A		50kA
	200-208V		220-240V		380-	-415V	4	40-480V
Code	200 HP		250-400	) HP	400-!	500 HP	45	50-500 HP
M - Standard	50A		50kA 50		OkA		50kA	
N - Intermediate	N/A		N/A		N/A			N/A
P - High	100kA		100kA		100kA			100kA
Q - Intermediate	N/A		N/A		N/A			N/A
	11/7		11//			,,,	1	,

For controller options and modifications see Publication OP10000-72.

# Modifications See Publication OP1000-72 Automatic Transfer

## Three Phase Voltage

Switch

A - 220-240 Volt, 60 Hertz (230 V)

AZ - 220-230 Volt, 50 Hertz

B - 440-480 Volt, 60 Hertz (460 V)

BZ - 415 Volt, 50 Hertz

C - 550-600 Volt, 60 Hertz (575 V)

F - 380 Volt, 60 Hertz

FZ - 380 Volt, 50 Hertz

FF - 400 Volt, 60 Hertz

FX - 400 Volt, 50 Hertz

H - 208 Volt, 60 Hertz

HH-200 Volt, 60 Hertz

Horsepower Rating	
03 - 3 HP	100 - 100 HP
05 - 5 HP	125 - 125 HP
07 - 7 1/2 HP	150 - 150 HP
10 - 10 HP	200 - 200 HP
15 - 15 HP	250 - 250 HP
20 - 20 HP	300 - 300 HP
25 - 25 HP	350 - 350 HP
30 - 30 HP	400 - 400 HP
40 - 40 HP	450 - 450 HP
50 - 50 HP	500 - 500 HP
60 - 60 HP	
75 - 75 HP	

## Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250



FTA1000 - FTA1930 With Opt. -TSA (FTA950)

## Mark III+ Electric Fire Pump Controllers

	SPECIAL ENCLOSURES
Option	Description
	Enclosure, NEMA Type 2 (IEC IP22), Painted Steel (Standard)
-E	Enclosure, NEMA Type 4 (IEC IP65), Painted Steel
-F	Enclosure, NEMA Type 4X (IEC IP66), #304 Stainless Steel, Brushed Finish
-FD	Enclosure, NEMA Type 4X (IEC IP66), #316 Stainless Steel, Brushed Finish
-FDB	Enclosure, NEMA Type 4X (IEC IP66), #316 Stainless Steel, Seam Welded, Brushed Finish
-FDP	Enclosure, NEMA Type 4X (IEC IP66), #316 Stainless Steel, Painted Finish
-FXP	Enclosure, NEMA Type 4X (IEC IP66), #304 Stainless Steel, Painted Finish
-G	Enclosure, NEMA Type 12 (IEC IP54), Painted Steel
-T	Enclosure, NEMA Type 3R (IEC IP24), Painted Steel
-U	Enclosure, NEMA Type 3 (IEC IP54), Painted Steel

## **CIRCUIT BREAKER OPTION**

Option	Description								
Standard S -M -R	Short Circui 200-208V 5-150 HP 100kA (M)	t Current R 220-240V 5-200 HP 100kA (M)	ating 380-415V 5-350 HP 100kA (M)	440-480V 5-400 HP 100kA (M)	550-600V 5-500 HP 50kA (R)	200-208V 200 HP 50kA (M)	220-240V 250-400 HP 50kA (M)	380-415V 400-500 HP 50kA (M)	440-480V 450-500 HP 50kA (M)
Intermedic -N -Q	ate Short Ci 200-208V 5-150 HP 150kA (N)	rcuit Curre 220-240V 5-200 HP 150kA (N)	nt Rating 380-415V 5-350 HP 150kA (N)	440-480V 5-400 HP 150kA (N)	550-600V 5-500 HP 100kA (Q)	200-208V 200 HP N/A	220-240V 250-400 HP N/A	380-415V 400-500 HP N/A	440-480V 450-500 HP N/A
High Short -P	Circuit Cur 200-208V 5-150 HP 200kA	rent Rating 220-240V 5-200 HP 200kA	380-415V 5-350 HP 200kA	440-480V 5-400 HP 200kA	550-600V 5-500 HP NA	200-208V 200 HP 100kA	220-240V 250-400 HP 100kA	380-415V 400-500 HP 100kA	440-480V 450-500 HP 100kA

## **ANTI-CONDENSATION SPACE HEATERS**

Option	Description
None	
- J	Space Heater, 120V Externally Powered with Circuit Breaker & Thermostat
-K	Space Heater, 120V Externally Powered with Circuit Breaker & Humidistat
-M	Space Heater, 240V Externally Powered with Circuit Breaker & Thermostat
-N	Space Heater, 240V Externally Powered with Circuit Breaker & Humidistat
-JKP	Space Heater, 120V Externally Powered with Circuit Breaker, Thermostat and Humidistat in Parallel
-MNP	Space Heater, 240V Externally Powered with Circuit Breaker, Thermostat and Humidistat in Parallel

## PRESSURE TRANSDUCERS, SOLENOID VALVES, PLUMBING

Option	Description
	Wetted Parts including Pressure Sensor and Test Solenoid, 300 PSI (20.4 Bar) Fresh Water
-B1	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar) Fresh Water (For Factory Calibration Purposes Only)
-C1	Wetted Parts including Pressure Sensor and Test Solenoid, 300 PSI (20.4 Bar), Sea Water
-D1	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water
-SP1	Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts
-SP2	Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contact

## FOAM PUMP APPLICATIONS Description

## Option

#### Required For Foam

-LR1 Low Foam Level External Input, Visible Indications and Alarm Contacts, Additive with Provisions for Proof Pressure Switch Connection, With Lockout and Remote Alarm Indication For Interlock On (Locked Out)

Required	Required For Foam				
-LK1	Foam Pump Application With Pressure Transducer and Run Test Solenoid Valve (Auto. Start)				
-LK2	Foam Pump Application With Pressure Transducer and Run Test Solenoid Valve, Stainless Steel (Auto. Start)				
-1 K3	Foam Pump Application Without Pressure Transducer and Run Test Solenoid Valve (Manual Start)				

ΔΙΔΡΜς

#### Optional For Foam

-DVC Operation, Dump Valve Control

Ontion	ALAKIVO
Option	Description
-AC	Extra Alarm Output Contacts, Pump Operating (2 Form-C)
-AM	Alarm Output Contacts, Fail to Start
-AV	Alarm Output Contacts, Low Pump Room Temperature
-AW	Alarm Output Contacts, Reservoir Low
-AYI	Configurable Low Suction Pressure, Visible/Output Contacts with External Digital Input
-BW1	Extra Alarm Output Contacts, Phase Failure/Phase Reversal
-BY1	Alarm Output Contacts, Overcurrent
-CTS1	Configurable Low Suction Pressure, Visible/Output Contacts with Suction Pressure Transducer
-EH1	Alarm Output Contacts, Main Relief Valve Open
-EK	Alarm Output Contacts, Flow Meter Open
-JR	Visible Indicator, Jockey Pump Operating
-JT	Alarm, Audible/Visible, Jockey Pump Trouble
-KH	Alarm Output Contacts, Common Alarm
-P1	Alarm, Audible/Visible, Built-In 120V Supervisory System (Includes Visible Supervisory Voltage Normal Indication and Audible Pump Operating, Phase Failure and Phase Reversal Indication
-PE	Alarm Output Contacts, Low System Pressure (Pump on Demand)
-PT	Alarm, Audible/Visible, Built-In 240V Supervisory System (Includes Visible Supervisory Voltage Normal Indication and Audible Pump Operating, Phase Failure and Phase Reversal Indication

#### Option Description -ED2 Normal Source Load Shedding with Adjustable Time Delay to Remove Non-Critical Loads Before Starting -EL Series Pumping Operation, High Zone Controller -EM Series Pumping Operation, Mid Zone Controller -EN Series Pumping Operation, Low Zone Controller Marking, CE with External Wet Parts (Requires NEMA Type 12 (IP54) Enclosure as Minimum) -IEC -MZN Neutral Lug, Service Entrance, Non-Insulated Bonded to Enclosure Seismic Certification compliant to OSHPD (CA) for rigid base or wall mount only -OSP -PK Terminal Blocks, Extra Remote Start -PY Output Contacts, Motor Space Heater, Externally Powered -S Tropicalization -SEI Seismic Certification compliant to CBC 2019, IBC 2018 for rigid base or wall mount only -USBX Data Port, External USB -ZPM1 Data Port, RS-485 Modbus RTU Controller Temperature Rating, 55°C (131°F) Ambient Temperature -Y55 -XCR Export Packaging (Wooden Crating to Conform to IPPC Standards)

**MISCELLANEOUS** 

## TRANSFER SWITCH ONLY OPTIONS


Option	Description
-EC	Extra Contacts for Remote Indication, Transfer Switch Position
-ED1	Alternate Source Load Shedding with Adjustable Time Delay to Remove Non-Critical Loads Before Starting

**Firetrol, Inc.** 3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com


## Dimensions and **Shipping Weight**



## MARKIII+ Electric Fire Pump Controllers - Wye-Delta Closed Transition Starting With Power Transfer Switch



NOTE:
DRAIN CONNECTION MUST
BE PIPED TO WASTE DRAIN.
FAILURE TO CONNECT TO A FLOOR
DRAIN WILL RESULT IN UNSAFE
CONDITIONS OF STANDING WATER
ADMINIS CONTROL IS AROUND CONTROLLER.



VOLTAGE/POWER TABLE				
LINE VOLTAGE	MOTOR HORSEPOWER			
208	75-100			
220-240	100-125			
380-400-415	150-200			
440-480	200-250			
600 250-350				
APPROX SHIPPING WT: 850 [386]				


#### NOTES:

- 1 STANDARD: NEMA 2
- 2. STANDARD PAINT: TEXTURED RED RAL3002
- 3. ALL DIMENSIONS IN INCHES [MILLIMETERS] SHIPPING WEIGHT IN POUNDS [KG]
- CENTER OF MARK III + SCREEN: 61 5/8 [1564] FROM BOTTOM OF ENCLOSURE
- 5. BOTTOM CONDUIT ENTRANCE THROUGH REMOVABLE GLAND PLATE RECOMMENDED
- USE WATERTIGHT CONDUIT AND CONNECTOR ONLY
- PROTECT EQUIPMENT AGAINST DRILLING CHIPS
- 8. DOOR SWING EQUAL TO DOOR WIDTH
- 9. DRAWINGS FOR CONSTRUCTION PURPOSES MUST BE OBTAINED FROM FIRETROL OR THE LOCAL FIRETROL REPRESENTATIVE
- 10. SEISMIC MOUNTING TO BE RIGID WALL AND BASE ONLY

					REMOVED BELL AND UPDATED THE MARKI	II TO MARKIII PLUS	С	-	CIR	CIR	10-27-21
	SIZE A	BY	DATE		REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE
	DRAWN BY	CIR	11-5-19	Firetrol, Inc.	DIMENSIONS & SHIPPING WEIGHT	FTA1350 WITH FTA950	DRAWING	NUMBER 350-8			
THIRD ANGLE PROJECTION		0			CLOSED TRANSITION WYE DELTA FIRE	DUMP CONTROLLER	וטטו	330-0			CDL
PROJECTION	FINAL APPROVAL	CIR	11-5-19	© Firetrol, Inc. Not for construction. Subject to change without notice.	AND POWER TRANSFER SWITCH	FOMF CONTROLLER	DWG C	ECN -		SH	HEET 1 OF 1



## MARKIII+ Electric Fire Pump Controllers - Wye-Delta Closed Transition Starting With Power Transfer Switch




Drawing for information only.

Manufacturer reserves the right to modify this drawing without notice.

Contact manufacturer for "As Built" drawing.

					REVISED J36, J38 CONNECTIONS		В	-	TEF	TEF	01/18/23
					UPDATED TO MARK III+		A	-	TEF	TEF	10/27/21
	SIZE B	BY	DATE		REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE
$\bigoplus \bigoplus$	DRAWN BY	JMW	12-2-19	<b>Firetrol, Inc.</b>	WIRING SCHEMATIC	FTA1350 W/FTA950	DRAWING N	iumber 350-8	Λ		
THIRD ANGLE PROJECTION		011111			CLOSED TRANSITION WYE DELTA FIRE	E PLIMP CONTROLLER	VV 3 I	350-6	U		CDL
PROJECTION	FINAL APPROVAL	CIR	12-2-19	© Firetrol, Inc. Not for construction. Subject to change without notice.	WITH POWER TRANSFER SWITCH	TOWN CONTROLLER	DWG B	ECN - NO -		SH	IEET 1 OF 1





Drawing for information only.

Manufacturer reserves the right to modify this drawing without notice.

Contact manufacturer for "As Built" drawing.

	VOLTAG	E/POWER TABLE
	LINE VOLTAGE	MOTOR HORSEPOWER
-	380-415	15-200
	440-480	15-250
	550-600	15-350

DRAWN BY CIR 12-9-19 THIRD ANGLE PROJECTION  FINAL APPROVAL CIR 12-9-19 FIN		SIZE B	BY	DATE		REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE
THIRD ANGLE PROJECTION FINAL CIR 12-9-19 © Firetrol, Inc. Not for construction.  FINAL CIR 12-9-19 © Firetrol, Inc. Not for construction.  FIRE PUMP TRANSFER SWITCH FOR GEN SET AND  DWG ECN SHEET 1 05-1		DRAWN BY	CIR	12-9-19	<b>Firetrol, Inc.</b>	WIRING SCHEMATIC	FTA950					
FINAL CIR 12-9-19 Priesto, inc. Not to consudction.	THIRD ANGLE		0111	12 0 10		EIDE DUMD TRANSEER SWITCH FOR C	113930-00					
			CIR	12-9-19	© Firetroi, inc. Not for construction.						SHE	EET 1 OF 1

## **Field Connections Alarm & Control Terminals**



## MARKIII+ Electric Fire Pump Controllers - Wye-Delta Closed Transition Starting

#### Control Terminals (EB1) Remote Alarm Terminals (EB1) Terminals Wire Size: 24 - 12 AWG 0.5 Nm Terminals Wire Size: 24 - 12 AWG 0.5 Nm Normally open Closes to alarm Normally closed Opens to alarm Remote Manual Start Motor Run Normally open Closes to alarm Normally closed Opens to alarm Normally open Closes to alarm Normally closed Opens to alarm Close to block start Lockout Power Avallable Normally open Closes to alarm Normally closed Opens to alarm ' Normally open Normally closed Closes to alarm Opens to alarm ' Remote Automatic Start Phase Reversal Normally open Closes to alarm Normally closed Normally open Closes to alarm Normally closed Open to start pump Opens to alarm ' Pump Room Alarm \*\* Deluge Valve Normally open Closes to alarm Normally closed Opens to alarm ' Normally open Closes to alarm Normally closed Alarm Inputs (EB1) Opens to alarm ' Motor Trouble \*\* Normally open Terminals Wire Size: 24 - 12 AWG 0.5 Nm Closes to alarm Normally closed Opens to alarm Normally open Closes to alarm Normally closed Opens to alarm ' (Field Programmable \*\*\*) Water Reservoir Low Close to signal alarm Normally open Closes to alarm Normally closed Opens to alarm

## Network Connection (VMB1)

Shielded Female Connector RJ45



<sup>\*</sup> Remove jumper to use this feature

Drawing for information only.

Manufacturer reserves the right to modify this drawing without notice.

Contact manufacturer for "As Built" drawing.

					RELEASED		-	-	CIR	CIR	11-11-19
	SIZE A	BY	DATE		REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE
				<b>F</b> Firetrol, Inc.	FIELD CONNECTIONS	FTA1350	DRAWING				
THIRD ANGLE	DRAWN BY	CIR	11-10-19		OLOGED TRANSITION WAVE BELTA FIRE	FC1	350-60			CDL	
PROJECTION	FINAL APPROVAL	CIR	11-10-19	© Firetrol, Inc. Not for construction. Subject to change without notice.	CLOSED TRANSITION WYE DELTA FIRE	: PUMP CONTROLLER	DWG REV -	ECN -		SH	HEET 1 OF 1
		formation co	ntained or depicted h	erein are the sole property of Firetrol, Inc. Copies are communicated to the re	ciplent in strict confidence and may not be retransmitted, published, reproduced, cop	led or used in any manor, including as the basis for the manufacture or			ress orlor	written con	nsent of Firetrol, Inc.

<sup>\*\*</sup> Re-assignable
\*\*\* Not available on FTA1930 models

## **Field Connections** Line & Motor Wire Terminal Capacity



## MARKIII+ Electric Fire Pump Controllers - Wye-Delta Closed Transition Starting

#### Line Terminals

## 3 Phases Incoming Power YYY TTT囡 000 L1 L2 L3 IS1

- 1 For proper wire sizing, refer to NFPA70 and NEC (USA) or CEC (Canada) or local code.
- Controller suitable for service entrance in USA.
   For more accurate motor connections refer to motor manufacturer or motor nameplate.
- 4 Controller is phase sensitive. Incoming lines must be connected in ABC sequence.


#### COPPER CONDUCTORS for Isolating Switch (IS1).

Field Wiring According to Bending Space (AWG or MCM). Terminals L1 - L2 - L3

Bending Space					8 " (203 mm)							
HP Voltage	5			15	20	25	30	40	50	60		
208	1x (10 to 1/0) 1x (8 to 1/0) 1x (8 to 1/0)		1x (8 to 1/0)	1x (6 to 1/0)	(6 to 1/0) 1x (4 to 1/0) 1x		1x (2 to 1/0)	1x (1/0 to 3/0)	1x (3/0 to 250)	1x (4/0 to 250)		
220 to 240	1x (10 to 1/0)	1x (10 to 1/0)	1x (8 to 1/0)	1x (6 to 1/0)	1x (4 to 1/0)	1x (4 to 1/0)	1x (3 to 1/0)	1x (1 to 3/0)	1x (2/0 to 3/0)	1x (3/0 to 250)		
380 to 416	1x (10 to 1/0)	1x (10 to 1/0)	1x (10 to 1/0)	1x (8 to 1/0)	1x (8 to 1/0)	1x (6 to 1/0)	1x (6 to 1/0)	1x (4 to 1/0)	1x (3 to 1/0)	1x (3 to 1/0)		
440 to 480	1x (10 to 1/0) 1x (10 to 1/0) 1x (10 to 1/0)		1x (10 to 1/0)	1x (8 to 1/0)	1x (8 to 1/0)	1x (6 to 1/0)	1x (6 to 1/0)	1x (4 to 1/0)	1x (3 to 1/0)			
600	1x (10 to 1/0)	1x (10 to 1/0)	1x (10 to 1/0)	1x (10 to 1/0)	1x (10 to 1/0)	1x (8 to 1/0)	1x (8 to 1/0)	1x (6 to 1/0)	1x (6 to 1/0)	1x (4 to 1/0)		

Bending Space		12	" (305 mm)		16 " (406 mm)								
HP Voltage	75	100	125	150	200	250	300	350	400	450	500		
208	2x (1/0 to 500)	2x (2/0 to 500)	2x (4/0 to 500)	2x (250 to 500)	3x (4/0 to 500)								
220 to 240	0 1x (250) 2x (2/0 to 500) 2x (3/0 to 500) 2x (4/0 to 500)				2x (350 to 500)	3x (250 to 500)							
380 to 416	1x (1/0 to 3/0)	1x (3/0 to 250)	1x (250)	2x (1/0 to 500)	2x (3/0 to 500)	2x (4/0 to 500)	2x (300 to 500)	2x (400 to 500)	3x (250 to 500)	3x (300 to 500)			
440 to 480	1x (1 to 3/0) 1x (2/0 to 3/0) 1x (3/0 to 250) 1x (4/0 to 250)				2x (1/0 to 500)	2x (3/0 to 500)	2x (4/0 to 500)	2x (300 to 500)	2x (350 to 500)	2x (400 to 500)	3x (250 to 500)		
600	1x (3 to 1/0)				1x (250)	2x (2/0 to 500)	2x (3/0 to 500)	2x (4/0 to 500)	2x (250 to 500)	2x (300 to 500)	2x (350 to 500)		
Bending Space	5 " (127 mm)		8 " (203 mm)		12 " (305 mm)								

## **Motor Terminals**



#### COPPER CONDUCTORS for Motor Connection (1M-2M).

Field Wiring According to Bending Space (AWG or MCM). Terminals T1-T2-T3-T4-T5-T6-T7-T8-T9

HP Voltage	5	7.5	10	15	20	25	30	40	50	60
208	1x (10 to 4)	1x (10 to 4)	1x (10 to 4)	1x (8 to 4)	1x (8 to 4)	1x (6 to 4)	1x (6 to 4)	1x (4 to 2/0)	1x (2 to 2/0)	1x (1 to 2/0)
220 to 240	1x (10 to 4)	1x (10 to 4)	1x (10 to 4)	1x (8 to 4)	1x (8 to 4)	1x (6 to 4)	1x (6 to 4)	1x (4)	1x (3 to 2/0)	1x (2 to 2/0)
380 to 416	1x (10 to 4)	1x (10 to 4)	1x (8 to 4)	1x (8 to 4)	1x (6 to 4)	1x (4)				
440 to 480	1x (10 to 4)	1x (10 to 4)	1x (10 to 4)	1x (8 to 4)	1x (8 to 4)	1x (6 to 4)				
600	1x (10 to 4)	1x (10 to 4)	1x (10 to 4)	1x (10 to 4)	1x (8 to 4)	1x (8 to 4)				
HP Voltage	75	100	125	150	200	250	300	350	400	450
208	1x (2/0 to 3/0)	1x (3/0 to 300)	1x (250 to 300)	2x (1/0 to 300)	2x (3/0 to 350)					

HP Voltage	75	100	125	150	200	250	300	350	400	450	500
208	1x (2/0 to 3/0)	1x (3/0 to 300)	1x (250 to 300)	2x (1/0 to 300)	2x (3/0 to 350)						
220 to 240	1x (1/0 to 2/0)	1x (3/0)	1x (4/0 to 300)	1x (300)	2x (2/0 to 300)	2x (4/0 to 350)					
380 to 416	1x (4 to 2/0)	1x (2 to 2/0)	1x (1/0 to 2/0)	1x (2/0 to 3/0)	1x (4/0 to 300)	1x (300)	2x (2/0 to 300)	2x (3/0 to 300)	2x (4/0 to 350)	2x (4/0 to 350)	
440 to 480	1x (4 to 2/0)	1x (3 to 2/0)	1x (2 to 2/0)	1x (1/0 to 3/0)	1x (2/0 to 3/0)	1x (4/0 to 300)	1x (300)	2x (1/0 to 300)	2x (2/0 to 300)	2x (3/0 to 350)	2x (4/0 to 350)
600	1x (6 to 4)	1x (4)	1x (3 to 2/0)	1x (2 to 2/0)	1x (1/0 to 3/0)	1x (2/0 to 3/0)	1x (4/0 to 300)	1x (250 to 300)	1x (300)	2x (1/0 to 300)	2x (2/0 to 300)

	SIZE A	BY	DATE
THIRD ANGLE	DRAWN BY	CIR	11-10-19
PROJECTION	FINAL APPROVAL	CIR	11-10-19




RELEASED		-	-	CIR	CIR	11-11-19
REVISION DESCRIPTION	REV	ECN NO	BY	APP	DATE	
FIELD CONNECTIONS	FTA1350	DRAWING I	NUMBER 350-61	1		
OLOGED TRANSITION MAYE BELTA FIRE	DUMP CONTROLLED	LC I	350-0	I		CDL
CLOSED TRANSITION WYE DELTA FIRE	DIMO -	ECN				
LINE AND MOTOR FIELD WIRE TERMIN.	REV A	NO -		SH	HEET 1 OF 1	



## Power Transfer Switch For Use With MarkIII+ Electric Fire Pump Controllers

#### Power Terminals



#### Notes:


1 - Controller is phase sensitive. Incoming lines must be connected in ABC sequence.

<u>COPPER CONDUCTORS</u> for Isolating Switch (AIS1).
Field Wiring According to Bending Space (AWG or MCM). Terminals AL1 - AL2 - AL3

I ICIG VVIII	ing According	According to bending Space (AWG or Michil). Terminals ALT - ALZ - ALS												
Bending Space				5 " (1	27 mm)				8 " (203 mm	)				
HP Voltage	5	7.5	10	10 15 20 25				40	50	60				
208	108 1x (10 to 1/0) 1x (8 to 1/0) 1x (8 to 1/0) 1				1x (4 to 1/0)	1x (3 to 1/0)	1x (2 to 1/0)	1x (1/0 to 3/0)	1x (3/0 to 250)	1x (4/0 to 250)				
220 to 240	1x (10 to 1/0)	1x (10 to 1/0)	1x (8 to 1/0)	1x (6 to 1/0)	1x (4 to 1/0)	1x (4 to 1/0)	1x (3 to 1/0)	1x (1 to 3/0)	1x (2/0 to 3/0)	1x (3/0 to 250)				
380 to 416	1x (10 to 1/0)	1x (10 to 1/0)	1x (10 to 1/0)	1x (8 to 1/0)	1x (8 to 1/0)	1x (6 to 1/0)	1x (6 to 1/0)	1x (4 to 1/0)	1x (3 to 1/0)	1x (3 to 1/0)				
440 to 480	0 480 1x (10 to 1/0) 1x (10 to 1/0) 1x (10 to 1/0) 1x (10 to 1/0)		1x (10 to 1/0)	1x (8 to 1/0)	1x (8 to 1/0)	1x (6 to 1/0)	1x (6 to 1/0)	1x (4 to 1/0)	1x (3 to 1/0)					
600	1x (10 to 1/0)	1x (10 to 1/0)	1x (10 to 1/0)	1x (10 to 1/0)	1x (10 to 1/0)	1x (8 to 1/0)	1x (8 to 1/0)	1x (6 to 1/0)	1x (6 to 1/0)	1x (4 to 1/0)				


Bending Space		12 "	' (305 mm)		16 " (406 mm)							
HP Voltage	75	100	125	150	200	250	300	350	400	450	500	
208	2x (1/0 to 500)	2x (2/0 to 500)	2x (4/0 to 500)	2x (250 to 500)	3x (4/0 to 500)							
220 to 240	1x (250)	2x (2/0 to 500)	2x (3/0 to 500)	2x (4/0 to 500)	2x (350 to 500)	3x (250 to 500)						
380 to 416	1x (1/0 to 3/0)	1x (3/0 to 250)	1x (250)	2x (1/0 to 500)	2x (3/0 to 500)	2x (4/0 to 500)	2x (300 to 500)	2x (400 to 500)	3x (250 to 500)	3x (300 to 500)		
440 to 480	1x (1 to 3/0)	1x (2/0 to 3/0)	1x (3/0 to 250)	1x (4/0 to 250)	2x (1/0 to 500)	2x (3/0 to 500)	2x (4/0 to 500)	2x (300 to 500)	2x (350 to 500)	2x (400 to 500)	3x (250 to 500)	
600	1x (3 to 1/0)	1x (1 to 3/0)	1x (2/0 to 3/0)	1x (3/0 to 250)	1x (250)	2x (2/0 to 500)	2x (3/0 to 500)	2x (4/0 to 500)	2x (250 to 500)	2x (300 to 500)	2x (350 to 500)	
Bending Space	5 " (127 mm)		8 " (203 mm)			12 " (305 mm)						

## Remote Alarm Terminals (TSB1)



## Control Terminals (TSB1)

Terminals Wire Size: 24 - 12 AWG 0.5 Nm



Drawing for information only.

Manufacturer reserves the right to modify this drawing with Contact manufacturer for "As Built" drawing.

	SIZE A	BY	DATE			
THIRD ANGLE	DRAWN BY	CIR	11-10-19			
PROJECTION	FINAL APPROVAL	CIR	11-10-19			




REVISED TO AGREE W/CURRENT MANUFAC	Α	-	CIR	CIR	1-14-21	ĺ	
REVISION DESCRIPTION	REV	DATE	ĺ				
FIELD CONNECTIONS	FTA950	DRAWING NUMBER					ĺ
POWER TRANSFER SWITCH FOR GENE SECOND UTILITY POWER SOURCE	FC950-65  DWG A ECN NO - SHEET 1						

## Typical Motor Connection Diagram



## Mark<sup>III+</sup> Electric Fire Pump Controllers - Wye-Delta Starting (12-Lead Motors)



FOR SINGLE VOLTAGE 12-LEAD WYE-DELTA MOTORS


- OR -

FOR DUAL VOLTAGE WYE-DELTA MOTORS CONNECTED TO OPERATE ON THE LOWER OF THE TWO VOLTAGES 200-208 FOR 200/400V RATED MOTORS OR 220-240 FOR 230/460V RATED MOTORS.

SIX (6) WIRES REQUIRED BETWEEN MOTOR AND CONTROLLER.

## IMPORTANT:

THIS DRAWING IS FOR GENERAL INFORMATION ONLY. REFER TO MOTOR CONNECTION DIAGRAM FOR SPECIFIC WIRING ARRANGEMENT.



FOR DUAL VOLTAGE WYE-DELTA MOTORS CONNECTED TO OPERATE ON THE *HIGHER* OF THE TWO VOLTAGES 440-480 FOR 230/460V RATED MOTORS OR 380-415 FOR 200/400V RATED MOTORS.

SIX (6) WIRES REQUIRED BETWEEN MOTOR AND CONTROLLER.

#### NOTES:

- 1. THREE (3) LEAD AND NINE (9) LEAD MOTORS *CANNOT* BE USED FOR WYE-DELTA STARTING.
- 2. TWELVE (12) LEAD PART WINDING MOTORS *CANNOT* BE USED FOR WYE-DELTA STARTING AT 240/230V.

B 280820 JMW TEF 09-12-19

	ADDED SINGLE VOLTAGE, 12 LEAD, Y-D MOTORS				Α	-	TEF	TEF	11-22-00		
THIRD ANGLE PROJECTION	SIZE A	BY	DATE		REVISION DESCRIPTION			ECN NO	BY	APP	DATE
					MOTOR COMMECTIONS	ETA 1000 / ETA 1050	DRAWING	IG NUMBER			
		10.43.67	09-12-95	<b>F</b> Firetrol, Inc.	MOTOR CONNECTIONS	FTA1300 / FTA1350					
		JIVIVV	03-12-33					NS1300-01			
	FINAL	TEF		© Firetrol, Inc. Not for construction. OPEN/CLOSED TRANSITION WYE-DELTA FIRE PUMP CONTROLLERS	D.110	5011		$\neg$			
	APPROVAL		TEF	09-12-95	Subject to change without notice.		DWG B	ECN 280	0820	) S⊦	SHEET 1 OF 1
				· · · · · · · · · · · · · · · · · · ·							
All rights reserved. The drawing and the Information contained or depicted herein are the sole property of Firetrol, Inc. Copies are communicated to the recipient in strict confidence and may not be retransmitted, published, reproduced, copied or used in any manor, including as the basis for the manufacture or sale of any products, without the express prior written consent of Firetrol, inc.											

UPDATED TITLE BLOCK