


Mark IIxe Electric Fire Pump Controllers

Field Connections FTA1250/950

Part Winding Starting W/ Power Transfer Switch




SPARE TERMINALS PROVIDED FOR PARALLEL CONNECTION OF REMOTE ALARMS (IF REQUIRED)

NOTE: TERMINALS FOR CUSTOMER CONNECTIONS REQUIRE 3.5MM SLOTTED SCREW DRIVER

TERMINAL TIGHTENING TORQUE				
TERMINAL TYPE	WIRE SIZE	TIGHTENING TORQUE		
CONTROL AND ALARM TERMINALS	#14-12 AWG [2.5-4 MM ²]	5.6 lb-in [.6 Nm]		


-NOTE-ALARM CONTACT RATING PILOT DUTY 250 VAC, 30 VDC 10 A. MAX. LOAD



NOTES

- 1— Incoming line terminals are provided to accommodate wire sizes at 125% of motor full load current per NFPA 70-2008, National Electrical Code, Table 430-250, Section 695.6(c), and Table 310-16, 75 rated Copper conductors.
- 2- Controller is phase rotation sensitive. Incoming lines L1, L2 and L3 must be in ABC, right hand rotation sequence for proper operation of the phase monitor.
- 3— Motor connections shown are typical. Since motor connections vary widely, refer to the motor connection diagram for specific wiring arrangement.
- 4- For Incoming line terminals and motor terminals field wire capacity refer to drawing FC1250-51

NOTE: USE COPPER CONDUCTORS ONLY FOR ALL CONNECTIONS



PRESSURE SYSTEM CONNECTION 1/2" FNPT

	SIZE A	BY	DATE
THIRD ANGLE	DRAWN BY	TEF	05-06-02
PROJECTION	FINAL APPROVAL	TEF	05-06-02



UPDATED TITLE BLOCK			280598	JMW	TEF	09-09-19	
ADD NOTE FOR COPPER CONDUCTORS ONLY, UPDATED LOGO AND TITLE BLOCK			226253	JC	TEF	12-09-09	
REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE	
FIELD CONNECTIONS	FTA1250 WITH FTA900, FTA950	DRAWING NUMBER FC1250-55					
DADT WINDING FIDE DUMP CONTRO	DT WILLIAM FIRE DUND CONTROLLED		FC1230 - 33				
PART WINDING FIRE PUMP CONTROLLER WITH POWER TRANSFER SWITCH		DWG B	ECN 280	ECN 280598 SH		HEET 1 OF 2	



Field Connections FTA1250/950

Part Winding Starting W/ Power Transfer Switch

Mark Ilxg Electric Fire Pump Controllers

