


#### Mark IIxg Electric Fire Pump Controllers



### A SPARE TERMINALS PROVIDED FOR PARALLEL CONNECTION OF REMOTE ALARMS (IF REQUIRED)


NOTE: TERMINALS FOR CUSTOMER CONNECTIONS REQUIRE 3.5MM SLOTTED SCREW DRIVER

TERMINAL TIGHTENING TORQUE		
TERMINAL TYPE	WIRE SIZE	TIGHTENING TORQUE
CONTROL AND ALARM TERMINALS	#14-12 AWG [2.5-4 MM <sup>2</sup> ]	5.6 lb—in [.6 Nm]



## Field Connections FTA1300 / FTA950


#### Wye-Delta Open Transition Starting With Power Transfer Switch



#### NOTES

- 1- Incoming line terminals are provided to accommodate wire sizes at 125% of motor full load current per NFPA 70-2008, *National Electrical Code*, Table 430-250, Section 695.6(c), and Table 310-16, 75' rated Copper conductors.
- 2- Controller is phase rotation sensitive. Incoming lines L1, L2 and L3 must be in ABC, right hand rotation sequence for proper operation of the phase monitor.
- 3- Motor connections shown are typical. Since motor connections vary widely, refer to the motor connection diagram for specific wiring arrangement.
- 4- For Incoming line terminals and motor terminals field wire capacity refer to drawing FC1300-51

NOTE: USE COPPER CONDUCTORS ONLY FOR ALL CONNECTIONS





TEF 12-09-09		
APP DATE		
DRAWING NUMBER FC1300-55		
FC1300-55		
SHEET 1 OF 2		
/		



# **Field Connections**

TEF 09-13-09

TEF 12-09-09

APF

DATE

SHEET 2 OF 2

#### FTA1300 / FTA950 Wye-Delta Open Transition Starting With Power Transfer Switch

