Field Connections



MarkIIxg Electric Fire Pump Controllers - Variable Speed Starting with Autotransformer Bypass and Power Transfer Switch

DRAWN BY TEF

TEF

FINAL

THIRD ANGLE ROJECTION


All rights reserved.

05/18/21

05/18/21


© Firetrol Inc. Not for construction

Subject to change without notice.



FTA3110M/FTA950

WIRE SIZE	WIRE SIZE
(CU)	SERVICE ENTRANCE
PER PHASE	GROUND LUG (CU)
#14 AWG-#1/0 AWG	(2) #14 AWG-#2/0 AWG
2.5 MM ² -50 MM ²	(2) 2.5 MM ² -70 MM ²
#4 AWG-300 kcmil	(2) #14 AWG-#2/0 AWG
25 MM ² -150 MM ²	(2) 2.5 MM ² -70 MM ²
#4 AWG-300 kcmil	(2) #6 AWG-250 kcmil
25 MM ² -150 MM ²	(2) 16 MM ² -120 MM ²
250 kcmil—500 kcmil	(2) #6 AWG-250 kcmil
120 MM ² —240 MM ²	(2) 16 MM ² -120 MM ²
#3/0 AWG-250 kcmil	(2) #6 AWG-250 kcmil
95 MM ² -120 MM ²	(2) 16 MM ² -120 MM ²
#2/0 AWG-400 kcmil	(2) #6 AWG-250 kcmil
70 MM ² -200 MM ²	(2) 16 MM ² -120 MM ²
#4/0 AWG-500 kcmil	(2) #6 AWG-250 kcmil
100 MM ² -240 MM ²	(2) 16 MM ² -120 MM ²



NOTES

- Incoming line terminals are provided to accommodate wire sizes at 125% of motor full load current per NFPA 70, National Electrical Code, Table 430-250, Section 695.6(c), and Table 310-16, 75° rated Copper conductors.
- Controller is phase rotation sensitive. Incoming lines L1, L2 and L3 must be in ABC, right hand rotation sequence for proper operation of the phase monitor.
- Motor connections shown are typical. Since motor connections vary widely, refer to the motor connection diagram for specific wiring arrangement.

REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE
FIELD CONNECTIONS FTA3110M WITH FTA950						
VFD ELECTRIC FIRE PUMP CONTROLLER WITH AUROTRANSFORMER BYPASS AND POWER TRANSFER SWITCH		- FC3110M-55				

are the sole property of Firetrol, Inc. Copies are communicated to the recipient in strict confidence and may not be retransmitted, published, reproduced, copied or used in any manor, including as the basis for the manufacture or sale of any products, without the express prior written consent of Firetrol, Inc.