


MARK Diesel Engine Fire Pump Controllers

Project Information



(DRAWINGS INCLUDED IN THIS PACKAGE ARE FOR STANDARD CONTROLLERS. ACTUAL "AS BUILT" DRAWINGS MAY DIFFER FROM THOSE SEEN HERE).

Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P 919 460 5200 F 919 460 5250 www.firetrol.com

Firetrol Mark^{III+} Diesel Engine Fire Pump Controller FTA1100J - 12 or 24 Volt

Specifications

1.0 Main Fire Pump Controller

The main fire pump controller shall be a factory assembled, wired and tested unit. The controller shall be of the combined manual and automatic type designed for diesel engine operation of the fire pump. The controller shall be rated for an Ambient Temperature Operating Range of 39°F (4°C) to 104°F (40°C).

1.1 Standards, Listings & Approvals

The controller shall conform to all the requirements of the latest editions of:

- · NFPA 20
- · UL (UL218 and CSA C22.2 No. 14)
- · FM Global (Class 1321/1323)
- · City of New York for fire pump service

1.2 Enclosure

The controller components shall be housed in a NEMA Type 2 (IEC IP22) dripproof, wall mounted enclosure with bottom entry gland plate.

1.3 Operator Interface (HMI)

7.0" LCD capacitive type color touch screen (HMI technology) operator interface powered by an embedded microcomputer with software PLC logic. Included shall be keypad type push-buttons for Crank from Battery #1, Crank from Battery #2, Stop and run test.

The screen shall include menus for: Home · Alarms · Configuration · History · Service · Manuals · Language.

The HMI shall graphically display the following: AC Power Present · Charger #1 & #2 Charging Mode · Battery #1 & #2 Voltage and Amperage · System Pressure · Cut In and Cut Out Pressure Settings · Starter #1 and #2 Cranking or Resting · Engine Running · Starting Cause · Fuel Valve Energized · Timers Operation · H-O-A Switch Position · Actuation Mode · Controller Type · Shutdown Mode · Time & Date · Pump Room Temperature · System Pressure

System pressure shall be capable of being displayed as: PSI, kPa, Bar, Feet of Head or Meters of Water.

The HMI shall allow programming and display of: Cut In & Cut Out Pressure Settings · Minimum Run Timer · Sequential Start Timer · Periodic Test Timer

The HMI allows the user to select the language of the system and download the manual or view the manual on screen.

1.4 State and Alarm Visual Indication

The digital display shall visually indicate and color code by criticalness the following:

AC Fail · DC Fail · Battery 1/2 Fail · Charger 1/2 Fail · Engine Trouble · Pump Room Trouble · Controller Trouble · Service Required · Battery 1/2 Weak · Loss of Continuity with Starting Contactor 1/2 · Weekly Test Start Pressure Not Reached · Weekly Test Check Solenoid Valve · Faulty Pressure Transducer · Low Raw Water Flow · Engine Fail When Running · Engine Fail To Start · Engine Overspeed · Low Ambient Temp. · Pump On Demand · Invalid Cut-In · Overpressure · Underpressure · Battery 1/2 Overvoltage · Water Reservoir Low · Fuel Tank Leak · Low Fuel Level · High Fuel Level · Engine ECM In Alternate Position · Engine Fuel Injection Malfunction · Engine High Temperature · Engine Low Temperature · Engine ECM Warning · Engine ECM Fault · Engine Low Oil Pressure · High Raw Water Temperature · Low Suction Pressure · Engine Run · Main Switch In Auto · Pump Room Temperature · Periodic Test · Main Switch in Hand · Cranking Cycle · Main Switch In Off · AC Power Available

1.5 Pressure and Event Recording

The system shall be capable of logging pressure data and operational events with time/date stamp. The system shall display operational events for the lifetime of the controller and display the pressure data in text or graphical form. The controller shall log the Date/Time of the first start-up and the controller total power on time from that date. The controller shall log first and last statistics for: First Setup · On Time · Engine On Time · Engine Start Count · Engine Last Start Time · Min/Max/Average System Pressure · Min/Max/Average Pump Room Temp · Jockey Pump On Time · Jockey Pump Start Count · Jockey Pump Last Start Time

1.6 USB Host Controller

A USB port capable of accepting a USB Flash Memory Disk shall be provided for downloading pressure and event logs.

1.7 Serial Communications

The controller shall feature Modbus with TCP/IP frame format and a shielded female RJ45 connector.

1.8 Pressure Sensing / Wet Parts

The controller shall be supplied with a solid state pressure transducer with a range of 0-500 psi calibrated for 0-300 psi (0-20.7 bar) and a run test solenoid valve. The wet parts shall be externally mounted and include a protective cover. The pressure sensing line connection to the transducer shall be 1/2-inch FNPT. Provisions for a redundant pressure transducer shall be provided.

1.9 Controller Operation

On a call to start, the controller will crank from battery 1 for 15 seconds then rest for 15 seconds before cranking on battery 2. This cranking cycle shall repeat 3 times. If a running signal is not received from the engine, the controller will alarm "Fail To Start".

The controller shall have the capability to schedule service reminders. The controller also provides for inputting of pump flow test data, generating and displaying the pump curve and permanently storing this data in memory.

Provisions shall be available for connection of external devices for Manual Remote Start, Automatic Remote Start and Deluge Valve Start.

DPDT dry contacts rated 8A - 250VAC shall be provided for remote indication of: Engine Run · Main Switch in Hand or Off · Controller Trouble (common) · Engine Trouble (common) · Pump Room Trouble (common)

An audible alarm device shall be provided on the controller.

2.0 Manufacturer

The controller shall be a Firetrol brand.





MARKIII+ Diesel Engine Fire Pump Controller



Description – Firetrol® combined automatic and manual Mark™ based diesel engine fire pump controllers are intended for starting and monitoring fire pump diesel engines. They are suitable for use with both mechanical and electronic type engines. The controller is available for 12 or 24 volt negative ground systems, using lead acid or Nickel-Cadmium batteries. The controller monitors, displays and records fire pump system information.

Approvals – Firetrol fire pump controllers are listed by Underwriters' Laboratories, Inc., in accordance with UL218, Standard for Fire Pump Controllers, CSA, Standard for Industrial Control Equipment (cUL), and approved by Factory Mutual. They are built to meet or exceed the requirements of the approving authorities as well as NEMA and the latest editions of NFPA 20, Installation of Centrifugal Fire Pumps, and NFPA 70, National Electrical Code.

Standard Features – The following are included as standard with each controller:

- NEMA Type 2 (IP22) Enclosure with Bottom Entry Gland Plate, Lifting Lugs and Locking Door Handle
- AC Line & Battery circuit breakers
- Two independent battery chargers, 10A continuous charge - 500mA Trickle Charge
- 7.0" LČD capacitive type color touch screen (HMI technology) software upgradeable operator interface powered by an embedded microcomputer with software PLC logic.
- Push-buttons for Crank from Battery #1, Crank from Battery #2, Stop and Run Test
- 500 PSI Pressure Transducer (calibrated for 300 PSI (20.7 Bar) and Test Solenoid for fresh water applications, externally mounted with protective cover
- Audible alarm buzzer embedded in the MarkIII+
- Pressure and Event Recording with Date Stamp to System Memory Accessible VIA The User Interface and Downloadable to a USB Flash Drive
- Visual Indication for: Engine Run Main Switch Position • Periodic Test • Cranking Cycle • AC Power Available • Pump Room Temperature
- Visual Alarm Indication for: Pump Room Trouble • Pump On Demand • AC Power Failure • Charger 1-2 Failure • Battery 1-2 Weak • Battery 1-2 Overvoltage • Loss of Continuity on Starter 1-2 • High Fuel Level • Fuel Tank Leak • PLD Low Suction Pressure • High Raw Water Temp.
 • Low Pump Room Temp. • High Pump Room Temp. • ECM Warning • Weekly Test Cut-In Pressure Not Reached • Check Weekly Test Solenoid • Pressure Transducer Fault • Invalid Cut-In Pressure • Service Required

- Audible and Visible Alarm Indication for: Engine Trouble • Controller Trouble
 Engine Low Oil Pressure • Engine High Temp. • Engine Low Temp. • Engine Overspeed • DC Failure • Battery 1-2 Failure • Engine Fail To Start • Low Fuel Level • ECM Fault • ECM SS In Alternate Position • Fuel Injection Malfunction
- DPDT 8A 250V Remote Alarm Contacts Are Provided For:
 - Engine Run
 - Common Controller Trouble (Charger Failure, Pressure Transducer Fault)
 - Common Engine Trouble (High Engine Temp., Fail To Start, Fuel Injection Malfunction, ECM Selector Switch in Alternate Position, Battery 1-2 Failure, DC Failure, Loss of Continuity to Starter 1-2, Engine Overspeed, Fail When Running, Low Oil Pressure, PLD Low Suction Pressure)
 - Common Pump Room Trouble (Low Fuel Level, High Fuel Level, Fuel Tank Leak, Low / High Pump Room Temperature, AC Power Failure, H-O-A Selector Switch in OFF or HAND)
- Modbus Communications with TCP/IP frame format and a shielded female RJ45 connector.
- Input Terminals for Connection to External Devices:
 - Low Fuel Level
 - Remote AUTOMATIC Start
 - Deluge Valve Start (re-assignable)
 - Fuel Tank Leak (re-assignable)
 - High Fuel Level (re-assignable)
- Pump Room Ambient Temperature Switch, Display and Alarms


For Model # Information See Publication SD1100-60
For Options and Modifications See
Publication OP1100-60

Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com



MARKIII+ Diesel Engine Fire Pump Controller



For Options and Modifications see Publication OP1100-60

Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com



MARKIII+ Diesel Engine Fire Pump Controller

Option	SPECIAL ENCLOSURES Description		
	Enclosure, NEMA Type 2 (IEC IP22), Painted Steel (Standard)		
-E	Enclosure, NEMA Type 4 (IEC IP65), Painted Steel		
-F	Enclosure, NEMA Type 4X (IEC IP66), #304 Stainless Steel, Brushed Finish		
-FD	Enclosure, NEMA Type 4X (IEC IP66), #316 Stainless Steel, Brushed Finish		
-FDB	Enclosure, NEMA Type 4X (IEC IP66), #316 Stainless Steel, Seam Welded, Brushed Finish		
-FDP	Enclosure, NEMA Type 4X (IEC IP66), #316 Stainless Steel, Painted Finish		
-FXP	Enclosure, NEMA Type 4X (IEC IP66), #304 Stainless Steel, Painted Finish		
-G	Enclosure, NEMA Type 12 (IEC IP54), Painted Steel		
-T	Enclosure, NEMA Type 3R (IEC IP24), Painted Steel		
-U	Enclosure, NEMA Type 3 (IEC IP54), Painted Steel		
Option	ENCLOSURE MOUNTING STANDS Description		
None			
-N30	Mounting Stand, Painted Steel		
-N30FXP	Mounting Stand, #304 Stainless Steel, Painted Finish		
-N30F	Mounting Stand, #304 Stainless Steel, Brushed Finish		
-N30DP	Mounting Stand, #316 Stainless Steel, Painted Finish		
-N30FD	Mounting Stand, #316 Stainless Steel, Brushed Finish		
Ontion	ANTI-CONDENSATION SPACE HEATERS		
Option	Description		
None			
-J	Space Heater, 120V Externally Powered with Circuit Breaker and Thermostat		
-K	Space Heater, 120V Externally Powered with Circuit Breaker and Humidistat		
-M	Space Heater, 240V Externally Powered with Circuit Breaker and Thermostat		
-N	Space Heater, 240V Externally Powered with Circuit Breaker and Humidistat		
-JKP -MNP	Space Heater, 120V Externally Powered with Circuit Breaker and Thermostat / Humidistat in Parallel Space Heater, 240V Externally Powered with Circuit Breaker and Thermostat / Humidistat in Parallel		
-WINF	Space neater, 240V Externally Powered with Circuit Breaker and Thermostat / Harrilastat in Parallel		
Option	PRESSURE TRANSDUCERS, SOLENOID VALVES, PLUMBING Description		
	Wetted Parts including Pressure Sensor and Test Solenoid, 300 PSI (20.4 Bar) Fresh Water		
-B1	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar) Fresh Water (For Factory Calibration Purposes Only)		
-C1	Wetted Parts including Pressure Sensor and Test Solenoid 300 PSI (20.4 Bar) Sea Water		
-C1	Wetted Parts including Pressure Sensor and Test Solenoid, 300 PSI (20.4 Bar), Sea Water Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water		
-C1 -D1 -SP1	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication		
-D1	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water		
-D1 -SP1	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts		
-D1 -SP1 -SP2	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts FOAM PUMP APPLICATIONS		
-Dl -SPl -SP2	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts FOAM PUMP APPLICATIONS Description		
-D1 -SP1 -SP2 Option Required F -LR1	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts FOAM PUMP APPLICATIONS Description or Foam Low Foam Level External Input, Visible Indications and Alarm Contacts, Additive with Provisions for Proof Pressure Switch Connection, With Lockout and Remote Alarm Indication For Interlock On (Locked Out)		
-DI -SP1 -SP2 Option Required F -LR1 Required F	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts FOAM PUMP APPLICATIONS Description or Foam Low Foam Level External Input, Visible Indications and Alarm Contacts, Additive with Provisions for Proof Pressure Switch Connection, With Lockout and Remote Alarm Indication For Interlock On (Locked Out)		
-D1 -SP1 -SP2 Option Required F	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts FOAM PUMP APPLICATIONS Description or Foam Low Foam Level External Input, Visible Indications and Alarm Contacts, Additive with Provisions for Proof Pressure Switch Connection, With Lockout and Remote Alarm Indication For Interlock On (Locked Out)		
-D1 -SP1 -SP2 Option Required F -LR1 Required F	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts FOAM PUMP APPLICATIONS Description or Foam Low Foam Level External Input, Visible Indications and Alarm Contacts, Additive with Provisions for Proof Pressure Switch Connection, With Lockout and Remote Alarm Indication For Interlock On (Locked Out) or Foam		
-D1 -SP1 -SP2 Option Required F -LR1 Required F -LK1	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts FOAM PUMP APPLICATIONS Description or Foam Low Foam Level External Input, Visible Indications and Alarm Contacts, Additive with Provisions for Proof Pressure Switch Connection, With Lockout and Remote Alarm Indication For Interlock On (Locked Out) or Foam Foam Pump Application With Pressure Transducer and Run Test Solenoid Valve, Stainless Steel		
-D1 -SP1 -SP2 Option Required F -LR1 Required F -LK1 -LK2	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts FOAM PUMP APPLICATIONS Description or Foam Low Foam Level External Input, Visible Indications and Alarm Contacts, Additive with Provisions for Proof Pressure Switch Connection, With Lockout and Remote Alarm Indication For Interlock On (Locked Out) or Foam Foam Pump Application With Pressure Transducer and Run Test Solenoid Valve Foam Pump Application With Pressure Transducer and Run Test Solenoid Valve, Stainless Steel Foam Pump Application Without Pressure Transducer and Run Test Solenoid Valve		

ALARI	ИS
Descrip	tion

Option	Description
-AC	Extra Alarm Output Contacts, Engine Running (3 Sets)
-AJ	Alarm Output Contacts, Engine Overspeed
-AK	Alarm Output Contacts, Low Oil Pressure
-AL	Alarm Output Contacts, High Water Temperature
-AM	Alarm Output Contacts, Fail To Start
-AN	Alarm Output Contacts, Battery / Charger Failure
-AP1	Alarm Output Contacts, Main Switch in "Hand"
-AR	Alarm Output Contacts, Main Switch in "Off"
-AS1	Extra Alarm Output Contacts, Main Switch in "Auto"
-ATI	Extra Alarm Output Contacts, Pump Room Trouble ¹
-AU	Alarm Output Contacts, Low Fuel Level
-AV	Alarm Output Contacts, Low Pump Room Temperature
-AW	Alarm Output Contacts, Reservoir Low ¹
-AYI	Configurable Low Suction Pressure Visible/Output Contacts with External Digital Input
-BTC	Alarm Output Contacts, Battery #1 & #2 Failure (Form-C SPDT)(Individual Outputs)
-CFC	Alarm Output Contacts, Battery Charger #1 & #2 Failure (Form-C SPDT)(Individual Outputs)
-CPL1	Alarm, Visible/Output Contacts, Overpressure
-CTS1	Configurable Low Suction Pressure, Visible/Output Contacts with Suction Pressure Transducer
-ECMFR	Alarm Output Contacts, Electronic Engine ECM Failure
	Alarm Output Contacts, Electronic Engine ECM Warning
	Extra Alarm Output Contacts, Engine Trouble (1 Set)
-EF	Extra Alarm Output Contacts, Main Switch Not in "Auto" (1 Set)
	Alarm Output Contacts, Main Relief Valve Open
-EK1	Alarm, Visible/Output Contacts, Flow Meter On
-GLS	Louver Activation Circuit (Battery Power Specific)
-HRTR	Alarm Output Contacts, High Raw Water Temperature
-LC	Alarm Output Contacts, High Fuel Level ¹
-LE1	Alarm Output Contacts, Fuel Spill
-LETR	Alarm Output Contacts, Low Engine Temperature
-LG	Alarm Output Contacts, Reservoir High ¹
-LRFR	Alarm Output Contacts, Low Raw Water Flow (Clogged Strainer)
-LSPR	Alarm Output Contacts, Low Suction Pressure (at Variable Speed Suction Limiting Engine Controls)
	Alarm Output Contacts, Low System Pressure (Pump On Demand)


MISCELLANEOUS Description

Option

AC Input, 220-240V
Provision for 4-20mA Flow Meter Signal Input with Monitoring and Display of Flow (Meter by Others) Do not use with option -EKA
Provision for 4-20mA Flow Meter Signal Input with Monitoring and Display of Flow and Adjustable Low and High Alarm Relays (Meter by Others) Do not use with option -EJA
Series Pumping Operation, High Zone Controller
Series Pumping Operation, Mid Zone Controller
Series Pumping Operation, Low Zone Controller
Marking, CE with External Wet Parts
Input Terminals, Shutdown Interlock
Seismic Certification compliant to OSHPD (CA) for rigid base or wall mount only
Tropicalization
Seismic Certification compliant to CBC 2019, IBC 2018 for rigid base or wall mount only
Data Port, External USB
Controller Temperature Rating, 55°C (131°F) Ambient Temperature
Export Packaging (Wooden Crating to Conform to IPPC Standards)
Data Port, RS485 Modbus RTU
K7A Low Fuel Level Switch 1.25" NPT - Field Adjustable from 2.75" to 27.5"
K7B Low Fuel Level Switch 1.50" NPT - Field Adjustable from 2.75" to 27.5"
K8A High Fuel Level Switch 1.25" NPT - Field Adjustable from 2.75" to 10.5"
K8B High Fuel Level Switch 1.50" NPT - Field Adjustable from 2.75" to 10.5"
K26A Combined High/Low Fuel Level Switch 1.25" NPT - Specify Diameter of Fuel Tank
K26B Combined High/Low Fuel Level Switch 1.50" NPT - Specify Diameter of Fuel Tank

Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com



- Standard: NEMA 2

recommended.

- Standard paint : textured red RAL 3002.

Use watertight conduit and connector only.
 Protect equipment against drilling chips.
 Door swing equal to door width.

		BY	DD/MM/YY
	DRAWN BY	ACD	28/02/23
	FINAL APPROVAL	FC	28/02/23

DIESEL ENGINE FIRE PUMP CONTROLLER 12VDC OR 24VDC NEGATIVE GROUND

2024 Firetrol Inc. All right reserved. This drawing and the information contained or depicted herein are the sole property of Firetrol Inc. Copies are communicated to the recipient in strict confidence and may not be retransmitted, published, reproduced, copied or used in any manner, including as the basis for the manufacture or sale of any products, without the express prior written consent of Firetrol Inc.


MODEL: FTA1100

BUILT TO THE LATEST EDITION OF THE NFPA20 & NFPA70





DRAWING NUMBER DD1100-800/E DWG REV. B SHEET 1 OF 1





© Firetrol, Inc. Not for construction.
Subject to change without notice.

	BY	DD/MM/YY
DRAWN BY	ACD	28/02/23
FINAL APPROVAL	FC	28/02/23

DIESEL ENGINE FIRE PUMP CONTROLLER 12VDC OR 24VDC NEGATIVE GROUND

MODEL:FTA1100

BUILT TO THE LATEST EDITION OF THE NFPA20 & NFPA70







THIRD ANGLE PROJECTION

DRAWING NUMBER
LY1100-800/E
DWG REV. 0
SHEET 1 OF 1


Designation	<u>Description</u>	
BC1-BC2	Battery Charger #1 and #2	
CB1-2	Magnetic Breaker 1 Pole 10 A	
CB3-4	Magnetic Breaker 1 Pole 16 A	
DB1	I/O Diesel Board	
F1	Filter	
IS1	Isolating Switch	
SS1	Lockable 3 Position Selector Switch	
MMB1	Main Board	






Front Door Layout

Internal Layout





* Remove this jumper to use this feature

	BY	DD/MM/YY
DRAWN BY	ACD	28/02/23
FINAL APPROVAL	FC	28/02/23


DIESEL ENGINE FIRE PUMP CONTROLLER 12VDC OR 24VDC NEGATIVE GROUND

MODEL: FTA1100

BUILT TO THE LATEST EDITION OF THE NFPA20 & NFPA70



DRAWING NUMBER
WS1100-800/E
DWG REV. 0
SHEET 2 OF 2





© Firetrol, Inc. Not for construction. Subject to change without notice.

	BY	DD/MM/YY
DRAWN BY	ACD	28/02/23
FINAL APPROVAL	FC	28/02/23

DIESEL ENGINE FIRE PUMP CONTROLLER 12VDC OR 24VDC NEGATIVE GROUND

MODEL: FTA1100

BUILT TO THE LATEST EDITION OF THE NFPA20 & NFPA70



Position

(Field

Programmabl

** Re-assignable

DRAWING NUMBER FC1100-800/E DWG REV. 0 SHEET 1 OF 1

I/O Diesel Board

NO

NO С NC

NO C


TB5

TB6

Power Supply

Terminals Wire Size: 14 - 6 AWG 1.8-2 Nm

110-240Vac 50-60Hz




Engine Connections

All wiring between the controller and diesel engine shall be stranded (NFPA20) Wiring between controller and engine (terminals 301, 302, 303, 304, 305, 310, 311, 312, 2, 3, 4, 5) must be #14AWG as minimum.


Wiring between controller and engine (terminals 12 [rated at 10A or 22A for 20 seconds] 1, 9, 10 [rated at 10A]) must be stranded #10AWG as minimum.

Wiring between controller and engine (terminals 6, 8, 11 [rated at 30A]) must be stranded and sized according to distance.

> 0-5' (0-1.5m) - 12 AWG (4 mm2) 6-10' (1.8-3m) - 10 AWG (6 mm2) 11-15' (3.3-4.5m) - 8 AWG (10 mm2) 16-20' (4.8-6m) - 2x10 AWG (2x6 mm2) 21-32' (6.4-9.75m) - 2x8 AWG (2x10 mm2)



Field Connections Terminals Wire Size: 24 - 12 AWG 0.5 Nm



Network Connections

Terminals Wire Size: Shielded Female Connector RJ45

Modbus TCP/IP---



Alarm Contacts

Terminals Wire Size: 24 - 12 AWG 0.5 Nm

Controller Trouble (Fail Safe)	Normally Opened Closes to alarm Normally Opened Closes to alarm	Normally Closed Opens to alarm Normally Closed Opens to alarm	1
Louver Activation Contact	Normally Closed Opens to Activate	Normally Opened Closes to activate O NO	
Engine Run	Normally Closed Opens to alarm	Normally Opened NO Closes to alarm NO C	2
HOA in OFF/HAND	Normally Closed Opens to alarm	Normally Opened Closes to alarm	3

Normally Opened

Closes to alarm


	Opens to alarm]		J@I	NC	
		`		le l	140	L
		Normally Opened	(NO	
		Closes to alarm	1	724		
	Normally Closed	<u> </u>	· (-01	С	\vdash
ine Trouble**	Opens to alarm	\		-01	NC	_
ine mouble	luble	Normally Opened	ſ	-0	NO	
	Normally Closed	Closes to alarm	· 1	<u> a</u>	С	L

_	Normally Closed Opens to alarm	Closes to alarm	{@
np Room uble**	Normally Closed	Normally Opened Closes to alarm	{
	Opens to alarm	l———	———

Normally Closed

le)	Normally Closed Opens to alarm	
	Normally Closed	

	0	NC	
Normally Opened Closes to alarm	0	NO	
<u> </u>	Ø	С	$\vdash \!\!\! \setminus^{T}$
\	0	NC	
Normally Opened	Ø	NO	
Closes to alarm	Ø	С	
\	0	NC	



2023 Firetrol Inc. All right reserved. This drawing and the information contained or depicted herein are the sole property of Firetrol Inc. Copies are communicated to the recipient in strict confidence and may not be retransmitted, published, reproduced, copied or used in any manner, including as the basis for the manufacture or sale of any products, without the express prior written consent of Firetrol Inc.