


MARKIII 1Ø Limited Service Electric Fire Pump Controller - Across The Line Starting With Power Transfer Switch

# **Project Information**



(DRAWINGS INCLUDED IN THIS PACKAGE ARE FOR STANDARD CONTROLLERS. ACTUAL "AS BUILT" DRAWINGS MAY DIFFER FROM THOSE SEEN HERE).

# Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P 919 460 5200 F 919 460 5250 www.firetrol.com

WWW.firetrol.com

While every precaution has been taken to ensure accuracy and completeness herein, Firetrol, Inc. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications and drawings are subject to change without notice. ©2019

Firetrol, Inc., All Rights Reserved.

# Firetrol Mark<sup>III</sup> Single Phase Limited ServiceElectric Fire Pump Controller

FTA740/FTA976 - 1Ø Full Voltage Starting With Power Transfer Switch Specifications

# 1.0 Main Fire Pump Controller

The main fire pump controller shall be a factory assembled, wired and tested unit. The controller shall be of the combined manual and automatic type designed for full voltage starting of the fire pump motor having the horsepower, voltage, phase and frequency rating shown on the plans and drawings.

# 1.1 Standards, Listings & Approvals

NFPA 20, Standard for the Installation of Stationary Pumps for Fire Protection NFPA 70, National Electrical Code.

The controller shall be listed by:

Underwriters Laboratories, Inc., in accordance with UL218, *Standard for Fire Pump Controllers* Canadian Standards Association CSA-C22.2, *Standard for Industrial Control Equipment* (cUL)

### 1.2 Enclosure

The controller components shall be housed in a NEMA Type 2 (IEC IP22) drip-proof, wall mounted enclosure with bottom entry gland plate and lifting lugs.

# 1.3 Withstand Ratings (Short Circuit Current Ratings)

All controller components shall be front mounted, wired and front accessible for maintenance. The available short circuit current ratings are shown below.

Code	200-208V	200-208V	220-240V	220-240
	1-2 HP	3-15 HP	1-3 HP	5-15 HP
D - Standard	65kA	65kA	65kA	65kA

# 1.4 Power Components

The controller shall include a thermal magnetic circuit breaker. The circuit breaker shall be mechanically interlocked so that the enclosure door cannot be opened with the handle in the ON position except by a hidden tool operated bypass mechanism. The circuit breaker shall be capable of being padlocked in the OFF position for installation and maintenance safety, and shall also be capable of being locked in the ON position without affecting the tripping characteristics of the circuit breaker. The controller door shall have a locking type handle. The controller shall be suitable for use as service equipment.

The controller will include a voltage surge arrestor and Across the Line motor starter. The controller shall be equipped with a single handle, manually operated, emergency start mechanism capable of being latched in the ON position.

The controller shall include an Automatic Transfer Switch, electrically or manually operated, mechanically held.

1.5 Operator Interface (HMI)

The operator interface shall be a 7.0" LCD color touch screen (HMI technology) powered by an embedded microcomputer with software PLC logic. Included shall be keypad type push-buttons for START, STOP, RUN TEST and TRANSFER SWITCH TEST. The screen shall include menus for: Home · Alarms · Configuration · History · Service · Manuals · Language.

The HMI shall graphically display the following: Voltage and Amperage of all 3 phases simultaneously using true RMS Technology for both the Normal and Alternate Power Sources · Transfer Switch Status · Motor Stopped/Running · Starting Cause · Actuation Mode · Controller Type · Shutdown Mode · Date & Time · Pump Room Temp. · System Pressure

System pressure shall be capable of being displayed as: PSI, kPa, Bar, Feet of Head or Meters of Water.

The HMI shall allow programming and display of: Cut In & Cut Out Pressure Settings · Minimum Run Timer · Sequential Start Timer · Periodic Test Timer

The HMI allows the user to select the language of the system and download the manual or view the manual on screen.

### 1.6 State and Alarm Indication

Visual indication shall be provided for the following:

Power Available • Motor Run • Periodic Test • Manual Start • Deluge Valve Start • Remote Automatic Start • Remote Manual Start • Emergency Start • Pump On Demand/Automatic Start • Pump Room Temperature • Lockout

The digital display shall visually indicate the following alarms:

Alternate Power Lock Rotor Current • Automatic Power Transfer Switch Trouble

• Locked Rotor Current • Fail To Start • Under/Over Current • Under/Over Voltage •

Check Test Solenoid Valve • Weekly Test Cut-In Not Reached • Transducer Fault •

Control Voltage Not Healthy • Motor Trouble • Pump Room Alarm • Invalid Cut-In • •

Power Loss • Low Water Level • Pump On Demand • Low Ambient Temp. • Service Required

Audible and visible alarm shall be provided for: Fail To Start • Alternate Circuit Breaker Off or Tripped

Remote Alarm contacts shall be provided for:

Power Available • Motor Run • Common Pump Room Alarm (Overvoltage, Undervoltage, Low/High Pump Room Temperature) • Common Motor Trouble (Overcurrent, Fail To Start, Undercurrent, Ground Fault) • Transfer Switch in Normal Position • Transfer Switch in Alternate Position • Alternate Power Isolating Switch

# 1.7 Pressure and Event Recording

The system shall be capable of logging pressure data and operational events with time/date stamp. The system shall display operational events for the lifetime of the controller and display the pressure data in text or graphical form. The controller shall log the Date/Time of the first start-up and the controller total power on time from that date. The controller shall log first and last statistics for: First Setup · On Time · Start Count · Last Start Time · Min/Max/Average System Pressure · Min/Max/Average Pump Room Temp. · Jockey Pump On Time/Start Count/Last Start Time · Phase to Phase Voltages with Date Stamp · Amps Per Phase with Date Stamp

### 1.8 USB Host Controller

A USB port capable of accepting a USB Flash Memory Disk shall be provided for downloading pressure and event logs.

### 1.9 Serial Communications

The controller shall feature Modbus with TCP/IP frame format and shielded female RJ45 connector

# 2.0 Pressure Sensing / Wet Parts

The controller shall be supplied with a solid state pressure transducer with a range of 0-500 psi calibrated for 0-300 psi (0-20.7 bar) and a run test solenoid valve. The wet parts shall be externally mounted and include a protective cover. The pressure sensing line connection to the transducer shall be 1/2-inch FNPT. Provisions for a redundant pressure transducer shall be provided.

### 2.1 Seismic Certification

The controller shall be certified to meet or exceed the requirements of the 2015 International Building Code, the 2016 California Building Code and OSHPD Special Seismic Certification Preapproval - OSP. The controller test criteria shall be per ICC-ES AC156 and the Seismic Parameters per ASCE 7-10 Chapter 13.

# 2.2 Controller Operation

The controller shall be capable of automatic starting via pressure drop, remote start signal from an automatic device or a deluge valve. The controller can be manually started via the START push-button, the RUN TEST push-button, or a remote signal from a manual device. Stopping can be achieved manually with the STOP push-button or automatically after expiration of minimum run timer or test timer. The minimum run timer (off delay), sequential start timer (on delay) and periodic test timer shall be field adjustable and include a visual countdown on the display. Adjustable timers shall be supplied for Momentary Normal Power Outage Override, Alternate Power Available Delay, Transfer Trouble Delay, Retransfer To Normal, Generator Cooldown.

## 2.3 Manufacturer

The controller shall be a Firetrol brand.

# **Product Description**



### MARKIII 10 Limited Service Electric Fire Pump Controllers - Across The Line Starting With Power Transfer Switch



**Description**—Firetrol® FTA750 Limited Service Controllers are intended for use with small electric motor driven fire pumps where the capacity of the power source permits full voltage starting. Full voltage is applied to the motor as soon as the controller is actuated. The controller monitors, displays and records fire pump system information.

Limited Sérvice Controllers may be used where they are acceptable to the authority having jurisdiction.

Power Transfer Switches are completely assembled with Firetrol Electric Fire Pump Controllers; full or reduced voltage types. The power transfer switches are built for use with generator set or 2nd utility use. The entire package of power transfer switch and controller is completely factory assembled, wired, tested and shipped as a compléte unit for easy field connection to the power sources and the fire pump motor.

Approvals – Firetrol fire pump controllers are listed by Underwriters' Laboratories, Inc., in accordance with UL218, Standard for Fire Pump Controllers, and CSA, Standard for Industrial Control Equipment. They are built to meet or exceed the requirements of the approving authorities as well as NEMA and the latest editions of NFPA 20, Installation of Centrifugal Fire Pumps, and NFPA 70, National Electrical Code.

The power transfer switches are listed by Underwriters' Laboratories, Inc., in accordance with UL218, Standard for Fire Pump Controllers; UL1008, Automatic Transfer Switches; UL508, Industrial Control Equipment, CSA, Standard for Industrial Control Equipment, and approved by Factory Mutual. They are built to meet or exceed the requirements of the approving authorities as well as NEMA and the latest editions of NFPA 20, Installation of Centrifugal Fire Pumps, and NFPA 70, National Electrical Code.

### Standard Features — The following are included as standard with each controller:

- Voltage surge protector
- Circuit Breaker (Inverse Time Non Adjustable rated between 150% and 250% of Motor Full Load Current
- Single Handle Circuit Breaker mechanism
- Single Handle Emergency Manual Run Mechanism to mechanically close motor contactor contacts in an emergency condition
- Built-in Start and Stop push-buttons to bypass automatic start circuits
- Daylight Savings Time Option
- Elapsed Time Meter

- 7.0" LCD color touch screen (HMI technology) soft-ware upgradeable operator interface powered by an embědded microcomputer with software PLĆ
- 500 PSI Pressure Transducer (calibrated for 300 PSI (20.7 Bar))and Test Solenoid fòr fresh water applications, externally mounted with protective cover
- Audible Alarm Bell
- Pump Room Ambient Temperature Switch, Display and Alarms
- Pressure and Event Recording with Date Stamp to System Memory Accessible VIA The User Interface and Downloadable to a USB Flash Drive
- Modbus Communications with TCP/IP frame format and a shielded female RJ45 connector
- NEMA Type 2 (IEC IP22) enclosure with bottom entry
- gland plate and lifting lugs Suitable for use as Service Equipment The controller supplies visual indication of the following: Power Available • Motor Run • Periodic Test • Manual Start • Deluge Valve Start • Remote Automatic Start • Remote Manual Start • Emergency Start • Pump On Demand (Automatic Start) • Pump Room Temp. • Lockout
- The controller displays visual indication for the following alarm conditions: Control Voltage Not Healthy • Invalid Cut-In • Lock Rotor Current • Loss of Power • Low Ambient Temp. • Low Water Level • Motor Trouble • Overcurrent • Overvoltage • Pressure Transducer Fault Detected • Pump On Demand • Pump Room Alarm • Service Required • Undercurrent • Undervoltage • Check Test Solenoid • Weekly Test Cut-In Reached
- Audible and Visible Indication for Fail To Start.
- DPDT 8A, 250VAC remote alarm contacts are provided for: Power Available Motor Run Common Pump Room Alarm (Overvoltage / Undervoltage / Low Pump Room Temp). + Common Motor Trouble (Overcurrent / Fail To Start / Undercurrent / Ground Fault)
- Field Adustable Timers with Visual Countdown for Minimum Run (Off Delay), Sequential Start (On Delay) and Weekly Test
- Seismic Certification per IBC 2015, CBC 2016 (Consult Factory for Verification)

### **Transfer Switch Standard Features** – The following are included as standard with each controller:

- Visual indication of the following: Alternate Power Lock Rotor Current Automatic Transfer Switch
- Audible and Visible indication of: Alternate Power Circuit Breaker OFF or Tripped • Alternate Power Isolating Switch Tripped/Open
  Transfer Switch test push-button
- Bypass for re-transfer and generator shutdown
- The following adjustable time delays are provided: Momentary Normal Power Outage Override Emergency Power Available Delay • Transfer Trouble Delay • Retransfer to Normal • Generator Cooldown
- Remote Alarm Contacts For: Emergency Isolating Switch Off • Transfer Switch in Normal Position Transfer Switch in Emergency Position

## **Product Description - Options & Modifications**

#### **SPECIAL ENCLOSURES**

- -E Enclosure, NEMA Type 4 (IP66), Painted Steel
- Enclosure, NEMA Type 4X (IP66), #304 Stainless Steel, Brushed Finish
- -FD Enclosure, NEMA Type 4X (IP66), #316 Stainless Steel, Brushed Finish
- -FDB Enclosure, NEMA Type 4X (IP66), #316 Stainless Steel,
   12 Gauge, Seam-Welded, Brushed Finish
- -FDP Enclosure, NEMA Type 4X (IP66), #316 Stainless Steel, Painted Finish
- -FXP Enclosure, NEMA Type 4X (IP66), #304 Stainless Steel, Painted Finish
- -G Enclosure, NEMA Type 12 (IP54), Painted Steel
- -T Enclosure, NEMA Type 3R (IP24), Painted Steel
- -U Enclosure, NEMA Type 3 (IP54), Painted Steel

### ANTI-CONDENSATION SPACE HEATERS

- Space Heater, 120V Externally Powered with Circuit Breaker and Thermostat
- -K Space Heater, 120V Externally Powered with Circuit Breaker and Humidistat
- Space Heater, 240V Externally Powered with Circuit Breaker and Thermostat
- Space Heater, 240V Externally Powered with Circuit Breaker and Humidistat
- -JKP Space Heater, 120V Externally Powered with Circuit Breaker and Thermostat and Humidistat in Parallel
- -MNP Space Heater, 240V Externally Powered with Circuit Breaker and Thermostat and Humidistat in Parallel

#### Pressure Transducers, Solenoid Valves, Plumbing

- -DI Wetted Parts Including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water
- -SX1 Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts
- -SX2 Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts

### ALARMS

- Alarm Output Contacts Extra, Pump Operating (1 Form A, 1 Form B)
- -AM Alarm Output Contacts, Fail to Start
- Alarm Output Contacts, Low Pump Room Temperature (Requires option -AF)
- -AW Alarm Output Contacts, Reservoir Low (Requires option -AG)
- -AYI Configurable Low Suction Pressure, Visible/Output
  Contacts with external digital input
- -BW1 Extra Alarm Output Contacts, Phase Failure/Phase Reversal
- -BY1 Alarm Output Contacts, Overcurrent
- -CTSI Configurable Low Suction Pressure, Visible/Output Contacts with Suction Pressure Transducer
- -EH1 Alarm, Visible/Output Contacts, Main Relief Valve Open
- -EK Alarm Visible/Output Contacts, Flow Meter Open
- -JR Visible Indicator, Jockey Pump Operating
- -JT Alarm, Audible/Visible, Jockey Pump Trouble

#### MISCELLANEOUS

- -EL Series Pumping Operation, High Zone Controller
- -EM Series Pumping Operation, Mid Zone Controller
- -EN Series Pumping Operation, Low Zone Controller
- -IEC Marking, CE with External Wet Parts
- -MZN Neutral Lug, Service Entrance, Non-insulated Bonded to Enclosure
- -PK Terminal Blocks, Extra Remote Start
- -PY Output Contacts, Motor Space Heater Circuit, Externally Powered
- -S Tropicalization
- -USBX Data Port, External USB
- -ZPM1 Data Port, RS485 Modbus RTU

### TRANSFER SWITCH OPTIONS

-EDI Permanent Load Shedding On Alternate Power With Adjustable Time Delay to Remove Non Critical Loads Before Starting

# ANTI-CONDENSATION SPACE HEATERS (Transfer Switch Side)

- -J1 Space Heater, 120V Externally Powered with Circuit Breaker and Thermostat
- -K1 Space Heater, 120V Externally Powered with Circuit Breaker and Humidistat
- -M1 Space Heater, 240V Externally Powered with Circuit Breaker and Thermostat
- -NI Space Heater, 240V Externally Powered with Circuit Breaker and Humidistat
- -JKP1 Space Heater, 120V Externally Powered with Circuit Breaker and Thermostat and Humidistat in Parallel
- -MNP1 Space Heater, 240V Externally Powered with Circuit Breaker and Thermostat and Humidistat in Parallel


Export packaging (Wooden crating to conform to IPPC Standards) FTA1000 - 1930

# Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com



MARK<sup>III</sup> 1Ø Limited Service Electric Fire Pump Controllers - Across The Line Starting With Power Transfer Switch



# Model Number Selection Guide - Options & Modifications

#### **SPECIAL ENCLOSURES**

- -E Enclosure, NEMA Type 4 (IP66), Painted Steel
- -F Enclosure, NEMA Type 4X (IP66), #304 Stainless Steel, Brushed Finish
- -FD Enclosure, NEMA Type 4X (IP66), #316 Stainless Steel, Brushed Finish
- -FDB Enclosure, NEMA Type 4X (IP66), #316 Stainless Steel, 12 Gauge, Seam-Welded, Brushed Finish
- -FDP Enclosure, NEMA Type 4X (IP66), #316 Stainless Steel, Painted Finish
- -FXP Enclosure, NEMA Type 4X (IP66), #304 Stainless Steel, Painted Finish
- -G Enclosure, NEMA Type 12 (IP54), Painted Steel
- -T Enclosure, NEMA Type 3R (IP24), Painted Steel
- -U Enclosure, NEMA Type 3 (IP54), Painted Steel

#### ANTI-CONDENSATION SPACE HEATERS

- Space Heater, 120V Externally Powered with Circuit Breaker and Thermostat
- -K Space Heater, 120V Externally Powered with Circuit Breaker and Humidistat
- Space Heater, 240V Externally Powered with Circuit Breaker and Thermostat
- -N Space Heater, 240V Externally Powered with Circuit Breaker and Humidistat
- -JKP Space Heater, 120V Externally Powered with Circuit Breaker and Thermostat and Humidistat in Parallel
- -MNP Space Heater, 240V Externally Powered with Circuit Breaker and Thermostat and Humidistat in Parallel

#### Pressure Transducers, Solenoid Valves, Plumbing

- -D1 Wetted Parts Including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water
- -SXI Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts
- -SX2 Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts

#### **ALARMS**

- Alarm Output Contacts Extra, Pump Operating (1 Form A, 1 Form B)
- -AM Alarm Output Contacts, Fail to Start
- -AV Alarm Output Contacts, Low Pump Room Temperature (Requires option -AF)
- -AW Alarm Output Contacts, Reservoir Low (Requires option -AG)
- -AYI Configurable Low Suction Pressure, Visible/Output Contacts with external digital input
- -BW1 Extra Alarm Output Contacts, Phase Failure/Phase Reversal
- -BYl Alarm Output Contacts, Overcurrent
- -CTS1 Configurable Low Suction Pressure, Visible/Output Contacts with Suction Pressure Transducer
- -EH1 Alarm, Visible/Output Contacts, Main Relief Valve Open
- -EK Alarm Visible/Output Contacts, Flow Meter Open
- -JR Visible Indicator, Jockey Pump Operating
- -JT Alarm, Audible/Visible, Jockey Pump Trouble

#### MISCELLANEOUS

- -EL Series Pumping Operation, High Zone Controller
- -EM Series Pumping Operation, Mid Zone Controller
- -EN Series Pumping Operation, Low Zone Controller
- -IEC Marking, CE with External Wet Parts
- -MZN Neutral Lug, Service Entrance, Non-insulated Bonded to Enclosure
- -PK Terminal Blocks, Extra Remote Start
- -PY Output Contacts, Motor Space Heater Circuit, Externally Powered
- -S Tropicalization
- -USBX Data Port, External USB
- -ZPM1 Data Port, RS485 Modbus RTU

### TRANSFER SWITCH OPTIONS

 -EDI Permanent Load Shedding On Alternate Power With Adjustable Time Delay to Remove Non Critical Loads Before Starting

# ANTI-CONDENSATION SPACE HEATERS (Transfer Switch Side)

- -J1 Space Heater, 120V Externally Powered with Circuit Breaker and Thermostat
- K1 Space Heater, 120V Externally Powered with Circuit Breaker and Humidistat
- Space Heater, 240V Externally Powered with Circuit Breaker and Thermostat
- -NI Space Heater, 240V Externally Powered with Circuit Breaker and Humidistat
- -JKP1 Space Heater, 120V Externally Powered with Circuit Breaker and Thermostat and Humidistat in Parallel
- MNP1 Space Heater, 240V Externally Powered with Circuit Breaker and Thermostat and Humidistat in Parallel


Export packaging (Wooden crating to conform to IPPC Standards)
FTA1000 - 1930


# Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com



### MARKIII 1Ø Limited Service Electric Fire Pump Controllers - Across The Line Starting With Power Transfer Switch





VOLTAGE/POWER TABLE									
LINE VOLTAGE/HZ	MOTOR HORSEPOWER								
1 PH									
	43E								
110-120/60	1-7.5								
200-208/50-60	3-15								
230-240/50-60	3-15								
APPROX SHIPE	PING WT: 180 [82]								

## NOTES:

- 1. STANDARD: NEMA 2
- 2. STANDARD PAINT: TEXTURED RED RAL3002
- 3. ALL DIMENSIONS IN INCHES [MILLIMETERS] SHIPPING WEIGHT IN POUNDS [KG]
- 4. CENTER OF MARK III SCREEN: 29 5/8 [751] FROM BOTTOM OF ENCLOSURE
- 5. BOTTOM CONDUIT ENTRANCE THROUGH REMOVABLE GLAND PLATE RECOMMENDED
- 6. USE WATERTIGHT CONDUIT AND CONNECTOR ONLY
- 7. PROTECT EQUIPMENT AGAINST DRILLING CHIPS
- 8. DOOR SWING EQUAL TO DOOR WIDTH
- 9. DRAWINGS FOR CONSTRUCTION PURPOSES MUST BE OBTAINED FROM FIRETROL OR THE LOCAL FIRETROL REPRESENTATIVE


					RELEASED		-	-	CIR	CIR	11-5-19
	SIZE A	BY	DATE		REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE
	DRAWN BY	CIR	11-5-19	<b>Firetrol, Inc.</b>	DIMENSIONS AND SHIPPING WEIGHT	FTA740 WITH FTA976	DRAWING	NUMBER 40-80			
THIRD ANGLE		0			OINOLE BUAGE LIMITED GEDVIOLEIDE	DUMP CONTROLLED	וטטו	40-00			
PROJECTION	FINAL APPROVAL	CIR	11-5-19	© Firetrol, Inc. Not for construction. Subject to change without notice.	SINGLE PHASE LIMITED SERVICE FIRE WITH POWER TRANSFER SWITCH		DWG REV -	ECN -			EET 1 OF 1
All rights reserved. Th	e drawing and the ir	nformation co	ntained or depicted i	erein are the sole property of Firetrol, Inc. Copies are communicated to the re	ciplent in strict confidence and may not be retransmitted, published, reproduced, cop	oled or used in any manor, including as the basis for the manufacture or	sale of any produ	cts, without the exp	ress prior v	vritten con	sent of Firetrol, Inc.

# **Field Connections** Line & Motor Wire Terminal Capacity



# MARKIII 1Ø Limited Service Electric Fire Pump Controllers - Across The Line Starting

Line Terminals



- Notes:

  1 For proper wire sizing, refer to NFPA70 and NEC (USA) or CEC (Canada) or local code.

  2 Controller suitable for service entrance in USA.

  3 For more accurate motor connections refer to motor manufacturer or motor nameplate.

  4 Controller is phase sensitive. Incoming lines must be connected in ABC sequence.

  5 Field wiring and lug sizes are based on copper conductors only.

Do no	t use	alum	niniur	n cor	iduc	tors.

Bending Space		3 " (76 mm)										
HP Voltage	1	3	5	7.5	10	15						
110 to 120	1x (10 to 1)	1x (8 to 1)	1x (6 to 1)	1x (4 to 1)	N/A	N/A						
200 to 208	N/A	1x (10 to 1)	1x (8 to 1)	1x (6 to 1)	1x (4 to 1)	1x (3 to 1)						
220 to 240	N/A	1x (10 to 1)	1x (8 to 1)	1x (8 to 1)	1x (6 to 1)	1x (3 to 1)						

HP Voltage	1	3	5	7.5	10	15
110 to 120	1x (10 to 1)	1x (8 to 1)	1x (6 to 1)	1x (4 to 1)	N/A	N/A
200 to 208	N/A	1x (10 to 1)	1x (8 to 1)	1x (6 to 1)	1x (4 to 1)	1x (3 to 1)
220 to 240	N/A	1x (10 to 1)	1x (8 to 1)	1x (8 to 1)	1x (6 to 1)	1x (3 to 1)

					RELEASED		-	-	CIR	CIR	11-12-19
	SIZE A	BY	DATE		REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE
	DRAWN BY	OID	11-12-19	<b>Firetrol. Inc.</b>	FIELD CONNECTIONS	FTA740	DRAWING I				
THIRD ANGLE	DRAWN BY	CIR	11-12-19	<b></b>	SINGLE PHASE LIMITED SERVICE FIRE	DUMP CONTROLLER	FC/	40-70			
PROJECTION	FINAL APPROVAL	CIR	11-12-19	© Firetrol, Inc. Not for construction. Subject to change without notice.	SINGLE PHASE LIMITED SERVICE FIRE		DWG REV -	ECN -			EET 1 OF 1

# Field Connections Alarm & Control Terminals



# MARKIII 10 Limited Service Electric Fire Pump Controllers - Across The Line Starting

#### Control Terminals (EB1) Remote Alarm Terminals (EB1) Terminals Wire Size: 24 - 12 AWG 0.5 Nm Terminals Wire Size: 24 - 12 AWG 0.5 Nm Normally open Closes to alarm Normally closed Opens to alarm Close to start pump Remote Manual Start Motor Run Normally open Closes to alarm Normally closed Opens to alarm Normally open Closes to alarm Normally closed Opens to alarm Lockout Power Available TB2 Normally open Closes to alarm Normally closed Opens to alarm ' Normally open Closes to alarm Normally closed Opens to alarm Open to start pump Remote Automatic Start (Field Programmable) Normally open Closes to alarm Normally closed Opens to alarm ' Normally open Normally closed Closes to alarm Opens to alarm Open to start pump Deluge Valve Pump Room Alarm \*\* Normally open Closes to alarm Normally closed Opens to alarm Normally open Closes to alarm Normally closed Alarm Inputs (EB1) Opens to alarm Motor Trouble \*\* Normally open Closes to alarm Normally closed Opens to alarm Normally open Normally closed Closes to alarm Close to signal alarm Opens to alarm ' Water Reservoir Low (Field Programmable) Normally open Normally closed Opens to alarm Network Connection (VMB1) Shielded Female Connector RJ45

\* Remove jumper to use this feature \*\* Re-assignable

Drawing for information only.

Manufacturer reserves the right to modify this drawing without notice.

Contact manufacturer for "As Built" drawing.

					RELEASED		-	-	CIR	CIR	11-12-19
	SIZE A	BY	DATE		REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE
	DRAWN BY	CIR	11-12-19	<b>Firetrol, Inc.</b>	FIELD CONNECTIONS	FTA740	DRAWING				
THIRD ANGLE	Diamit B.	CIIX	11 12 13		OINOLE BUAGE LIMITED OFFINIOE FIRE	DUMP CONTROLLER	FC/	40-71			
PROJECTION	FINAL APPROVAL	CIR	11-12-19	© Firetrol, Inc. Not for construction. Subject to change without notice.	SINGLE PHASE LIMITED SERVICE FIRE	PUMP CONTROLLER	DWG REV -	ECN NO -		SH	HEET 1 OF 1
All rights reserved. The	drawing and the in	formation co	ntained or depicted h	erein are the sole property of Firetrol, Inc. Copies are communicated to the re	cipient in strict confidence and may not be retransmitted, published, reproduced, cop	ied or used in any manor, including as the basis for the manufacture or	sale of any produ	ts, without the ext	ress prior v	ritten con	sent of Firetrol, Inc.


I/O

Modbus TCP/IP ----



# Power Transfer Switch For Use With Mark 10 Limited Service Electric Fire Pump Controllers

### **Power Terminals**



#### Notes:


- Controller is phase sensitive. Incoming lines must be connected in ABC sequence.
- Field wiring and lug sizes are based on copper conductors only.

  Do not use aluminium conductors.

Circuit Breaker (CB) Field Wiring according to Bending Space (AWG or MCM). TERMINALS L1 - L2												
	3 " (76 mm) (Use Copper Conductors Only)											
1	3	5	7.5	10	15							
1x (10 to 1)	1x (8 to 1)	1x (6 to 1)	1x (4 to 1)	N/A	N/A							
N/A	1x (10 to 1)	1x (8 to 1)	1x (6 to 1)	1x (4 to 1)	1x (3 to 1)							
N/A	1x (10 to 1)	1x (8 to 1)	1x (8 to 1)	1x (6 to 1)	1x (3 to 1)							
	1 1x (10 to 1) N/A	1 3  1x (10 to 1) 1x (8 to 1)  N/A 1x (10 to 1)	1 3 5 1x (10 to 1) 1x (8 to 1) 1x (6 to 1) N/A 1x (10 to 1) 1x (8 to 1)	3 " (76 mm)  1 3 5 7.5  1x (10 to 1) 1x (8 to 1) 1x (6 to 1) 1x (4 to 1)  N/A 1x (10 to 1) 1x (8 to 1) 1x (6 to 1)	3 " (76 mm)  1 3 5 7.5 10  1x (10 to 1) 1x (8 to 1) 1x (6 to 1) 1x (4 to 1) N/A  N/A 1x (10 to 1) 1x (8 to 1) 1x (6 to 1) 1x (4 to 1)							

### Remote Alarm Terminals (TSB1)

Terminals Wire Size: 24 - 12 AWG 0.5 Nm



### Control Terminals (TSB1)

Terminals Wire Size 24 - 12 AWG 0.5 Nm




	SIZE A	BY	DATE
THIRD ANGLE	DRAWN BY	CIR	11-10-19
PROJECTION	FINAL APPROVAL	CIR	11-10-19



	RELEASED		-	-	CIR	CIR	11-11-19	
	REVISION DESCRIPTION	REV	ECN NO	BY	APP	DATE		
,	FIELD CONNECTIONS	DRAWING	NUMBER 76-60					
	LIMITED SERVICE CONTROLLER POWE FOR GEN-SET AND SECOND UTILITY PO		DWG REV -	ECN NO -		SI	HEET 1 OF 1	



# MARKIII 1Ø Limited Service Electric Fire Pump Controllers - Across The Line Starting With Power Transfer Switch



<sup>\*</sup> Remove jumper to use this feature

Drawing for information only.

Manufacturer reserves the right to modify this drawing without notice.


Contact manufacturer for "As Built" drawing.

	SIZE B	BY	DATE		REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE
$\Rightarrow$	DRAWN BY	JMW	12-2-19	<b>Firetrol, Inc.</b>	WIRING SCHEMATIC	FTA740 WITH FTA976	DRAWING	NUMBER 40-80			
THIRD ANGLE PROJECTION		310100	12 2 10		SINGLE PHASE LIMITED SERVICE FIRE	DUMP CONTROLLER	VV31	40-00			CDL
PROJECTION	FINAL APPROVAL	CIR	12-2-19	© Firetion, inc. Not for construction.	WITH POWER TRANSFER SWITCH	FOMF CONTROLLER	DWG REV -	ECN NO		s⊦	HEET 1 OF 1
All rights reserved. The	e drawing and the in	nformation co	ontained or depicted i	erein are the sole property of Firetrol, inc. Copies are communicated to the re	ciplent in strict confidence and may not be retransmitted, published, reproduced, co	pled or used in any manor, including as the basis for the manufacture or	sale of any produc	ts, without the exp	ress prior v	vritten con	sent of Firetrol, Inc.

<sup>\*\*</sup> Contact closes when emergency start is in "ON" position



Power Transfer Switch For Use With Mark IØ Limited Service Electric Fire Pump Controllers



Drawing for information only.


Manufacturer reserves the right to modify this drawing without notice.

Contact manufacturer for "As Bullt" drawing.

THIRD ANGLE PROJECTION	SIZE B	BY	DATE		REVISION DESCRIPTION			ECN NO	BY	APP	DATE
		JIMW	12/10/19	© Firetrol, Inc. Not for construction. Subject to change without notice.	WIRING SCHEMATIC	FTA976	DRAWING				
					LIMITED SERVICE CONTROLLER POWER TRANSFER SWITCH FOR GEN-SET AND SECOND UTILITY POWER SOURCE, 220-240V SINGLE PHASE  closert in strict confidence and may not be retransmitted, published, reproduced, copied or used in any manor, including as the basis for the manufacture or		DWG	WS976-60			CDL
	APPROVAL	APPROVAL CIR 12/10/18	12/10/19				REV -	v - NO -		,	HEET 1 OF 1



Power Transfer Switch For Use With Mark<sup>III</sup> 1Ø Limited Service Electric Fire Pump Controllers



Drawing for information only.

Manufacturer reserves the right to modify this drawing without notice.

Contact manufacturer for "As Built" drawing.

							REV			——	
	SIZE B	BY	DATE	<b>Firetrol, Inc.</b>	REVISION DESCRIPTION			ECN NO	BY	APP DA	TE
THIRD ANGLE PROJECTION	<b>}</b>	BY JMW	12/10/19		WIRING SCHEMATIC	FTA976	DRAWING NUMBER				
	E DRAWN BT				LIMITED SERVICE CONTROLLER POWER TRANSFER SWITCH FOR GEN-SET			WS976-62			CDL
	FINAL APPROVAL	CIR	12/10/19	© Firetrol, Inc. Not for construction. Subject to change without notice.	AND SECOND UTILITY POWER SOURCE, 120V, SINGLE PHASE		DWG REV -	ECN - NO -		SHEET 1	OF 1