

MARK^{III} Limited Service Electric Fire Pump Controller - Across The Line Starting with Power Transfer Switch

Project Information

VOLTAGE/POWER TABLE									
LINE VOLTAGE/HZ	MOTOR HORSEPOWER								
200-208/50-60	3-30								
230-240/50-60	3-30								

(DRAWINGS INCLUDED IN THIS PACKAGE ARE FOR STANDARD CONTROLLERS. ACTUAL "AS BUILT" DRAWINGS MAY DIFFER FROM THOSE SEEN HERE).

Firetrol, **Inc.** 3412 Apex Peakway

Apex, North Carolina 27502 P 919 460 5200 F 919 460 5250 www.firetrol.com While every precaution has been take damages resulting from use of this in

WWW.firetrol.com While every precaution has been taken to ensure accuracy and completeness herein, Firetrol, Inc. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications and drawings are subject to change without notice. ©2019 Firetrol, Inc., All Rights Reserved.

Publication SBP750-80-240 Rev. A

Firetrol Mark^{III} Limited ServiceElectric Fire Pump Controller FTA750/FTA976 - Full Voltage Starting With Power Transfer Switch Specifications

1.0 Main Fire Pump Controller

The main fire pump controller shall be a factory assembled, wired and tested unit. The controller shall be of the combined manual and automatic type designed for full voltage starting of the fire pump motor having the horsepower, voltage, phase and frequency rating shown on the plans and drawings.

1.1 Standards, Listings & Approvals

NFPA 20, Standard for the Installation of Stationary Pumps for Fire Protection NFPA 70, National Electrical Code.

The controller shall be listed by:

Underwriters Laboratories, Inc., in accordance with UL218, *Standard for Fire Pump Controllers* Canadian Standards Association CSA-C22.2, *Standard for Industrial Control Equipment* (cUL)

1.2 Enclosure

The controller components shall be housed in a NEMA Type 2 (IEC IP22) drip-proof, wall mounted enclosure with bottom entry gland plate and lifting lugs.

1.3 Withstand Ratings (Short Circuit Current Ratings)

All controller components shall be front mounted, wired and front accessible for maintenance. The available short circuit current ratings are shown below.

Code	200-208V	200-208V	220-240V	220-240V	380-415V
	3-5 HP	7.5-30 HP	3-7.5 HP	10-30 HP	5-10 HP
M - Standard	65kA	65kA	65kA	65kA	25kA
N - Intermediate	N/A	100kA	N/A	100kA	N/A
	380-415V	440-480V	440-480V	550-600V	550-600V
Code	15-30 HP	5-15 HP	20-30 HP	5-20 HP	25-30 HP
M - Standard	25kA	25kA	25kA	18kA	18kA
N - Intermediate	65kA	N/A	65kA	N/A	25kA

1.4 Power Components

The controller shall include a circuit breaker (inverse time non adjustable) rated between 150% and 250% of motor full load current, mechanically interlocked and operated with a single, externally mounted handle. The circuit breaker shall be mechanically interlocked so that the enclosure door cannot be opened with the handle in the ON position except by a hidden tool operated bypass mechanism. The circuit breaker shall be capable of being padlocked in the OFF position for installation and maintenance safety, and shall also be capable of being locked in the ON position without affecting the tripping characteristics of the circuit breaker.

The controller will include a voltage surge arrestor and Across the Line motor starter. The controller shall be equipped with a single handle, manually operated, emergency start mechanism capable of being latched in the ON position.

The controller shall include an Automatic Transfer Switch, electrically or manually operated, mechanically held.

1.5 Operator Interface (HMI)

The operator interface shall be a 7.0" LCD color touch screen (HMI technology) powered by an embedded microcomputer with software PLC logic. Included shall be keypad type push-buttons for START, STOP, RUN TEST and TRANSFER SWITCH TEST. The screen shall include menus for: *Home · Alarms · Configuration · History · Service · Manuals · Language*.

The HMI shall graphically display the following: Voltage and Amperage of all 3 phases simultaneously using true RMS Technology for both the Normal and Alternate Power Sources · Transfer Switch Status · Motor Stopped/Running · Starting Cause · Actuation Mode · Controller Type · Shutdown Mode · Date & Time · Pump Room Temp. · System Pressure

System pressure shall be capable of being displayed as: *PSI, kPa, Bar, Feet of Head or Meters of Water.*

The HMI shall allow programming and display of: Cut In & Cut Out Pressure Settings · Minimum Run Timer · Sequential Start Timer · Periodic Test Timer

The HMI allows the user to select the language of the system and download the manual or view the manual on screen.

1.6 State and Alarm Indication

Visual indication shall be provided for the following: Power Available • Motor Run • Periodic Test • Manual Start • Deluge Valve Start • Remote Automatic Start • Remote Manual Start • Emergency Start • Pump On Demand/Automatic Start • Pump Room Temperature • Lockout

The digital display shall visually indicate the following alarms: Alternate Power Lock Rotor Current • Alternate Power Phase Reversal • Automatic Power Transfer Switch Trouble • Locked Rotor Current • Fail To Start • Under/Over Current • Under/Over Voltage • Phase Unbalance • Check Test Solenoid Valve • Weekly Test Cut-In Not Reached • Transducer Fault • Control Voltage Not Healthy • Motor Trouble • Pump Room Alarm • Invalid Cut-In • Phase Reversal • Power Loss • Phase Loss L1 / L2 / L3 • Low Water Level • Pump On Demand • Low Ambient Temp. • Service Required

Audible and visible alarm shall be provided for: Fail To Start • Alternate Circuit Breaker Off or Tripped • Alternate Isolating Switch Tripped/ Open •

Remote Alarm contacts shall be provided for: Power Available • Phase Reversal • Motor Run • Common Pump Room Alarm (Overvoltage, Undervoltage, Phase Unbalance, Low/High Pump Room Temperature) • Common Motor Trouble (Overcurrent, Fail To Start, Undercurrent, Ground Fault) • Transfer Switch in Normal Position • Transfer Switch in Alternate Position • Alternate Power Isolating Switch Off

1.7 Pressure and Event Recording

The system shall be capable of logging pressure data and operational events with time/date stamp. The system shall display operational events for the lifetime of the controller and display the pressure data in text or graphical form. The controller shall log the Date/Time of the first start-up and the controller total power on time from that date. The controller shall log first and last statistics for: *First Setup · On Time · Start Count · Last Start Time · Min/Max/Average System Pressure · Min/Max/Average Pump Room Temp. · Jockey Pump On Time/Start Count/Last Start Time · Phase to Phase Voltages with Date Stamp · Amps Per Phase with Date Stamp*

1.8 USB Host Controller

A USB port capable of accepting a USB Flash Memory Disk shall be provided for downloading pressure and event logs.

1.9 Serial Communications

The controller shall feature Modbus with TCP/IP frame format and shielded female RJ45 connector

2.0 Pressure Sensing / Wet Parts

The controller shall be supplied with a solid state pressure transducer with a range of 0-500 psi calibrated for 0-300 psi (0-20.7 bar) and a run test solenoid valve. The wet parts shall be externally mounted and include a protective cover. The pressure sensing line connection to the transducer shall be 1/2-inch FNPT. Provisions for a redundant pressure transducer shall be provided.

2.1 Seismic Certification


The controller shall be certified to meet or exceed the requirements of the 2015 International Building Code, the 2016 California Building Code and OSHPD Special Seismic Certification Preapproval - OSP. The controller test criteria shall be per ICC-ES AC156 and the Seismic Parameters per ASCE 7-10 Chapter 13.

2.2 Controller Operation

The controller shall be capable of automatic starting via pressure drop, remote start signal from an automatic device or a deluge valve. The controller can be manually started via the START push-button, the RUN TEST push-button, or a remote signal from a manual device. Stopping can be achieved manually with the STOP push-button or automatically after expiration of minimum run timer or test timer. The minimum run timer (off delay), sequential start timer (on delay) and periodic test timer shall be field adjustable and include a visual countdown on the display. Adjustable timers shall be supplied for Momentary Normal Power Outage Override, Alternate Power Available Delay, Transfer Trouble Delay, Retransfer To Normal, Generator Cooldown.

2.3 Manufacturer

The controller shall be a Firetrol brand.



Product Description



MARKIII Limited Service Electric Fire Pump Controllers - Across The Line Starting With Power Transfer Switch



Description—Firetrol® FTA750 Limited Service Controllers are intended for use with small electric motor driven fire pumps where the capacity of the power source permits full voltage starting. Full voltage is applied to the motor as soon as the controller is actuated. The controller monitors, displays and records fire pump system information.

Limited Service Controllers may be used where they are acceptable to the authority having jurisdiction.

Power Transfer Switches are completely assembled with Firetrol Electric Fire Pump Controllers; full or reduced voltage types. The power transfer switches are built for use with generator set or 2nd utility use. The entire package of power transfer switch and controller is completely factory assembled, wired, tested and shipped as a complete unit for easy field connection to the power sources and the fire pump motor.

Approvals – Firetrol fire pump controllers are listed by Underwriters' Laboratories, Inc., in accordance with UL218, *Standard for Fire Pump Controllers*, and CSA, *Standard for Industrial Control Equipment*. They are built to meet or exceed the requirements of the approving authorities as well as NEMA and the latest editions of NFPA 20, *Installation of Centrifugal Fire Pumps*, and NFPA 70,

National Electrical Code.

The power transfer switches are listed by Underwriters' Laboratories, Inc., in accordance with UL218, *Standard for Fire Pump Controllers*; UL1008, *Automatic Transfer Switches*; UL508, *Industrial Control Equipment*, CSA, *Standard for Industrial Control Equipment*; and approved by Factory Mutual. They are built to meet or exceed the requirements of the approving authorities as well as NEMA and the latest editions of NFPA 20, *Installation of Centrifugal Fire Pumps*, and NFPA 70, *National Electrical Code*.

- Standard Features The following are included as standard with each controller:
- Voltage surge protector
- Circuit Breaker' (Inverse Time Non Adjustable rated between 150% and 250% of Motor Full Load Current
- Single Handle Circuit Breaker mechanism
- Single Handle Emergency Manual Run Mechanism to mechanically close motor contactor contacts in an emergency condition
- Built-in Start and Stop push-buttons to bypass automatic start circuits
- Daylight Savings Time Option
- Elapsed Time Meter
- 7.0" LCD color touch screen (HMI technology) software upgradeable operator interface powered by an embedded microcomputer with software PLC logic.
- 500 PSI Pressure Transducer (calibrated for 300 PSI (20.7 Bar))and Test Solenoid for fresh water applications, externally mounted with protective cover
- Audible Alarm Bell
- Pump Room Ambient Temperature Switch, Display and Alarms

- Pressure and Event Recording with Date Stamp to System Memory Accessible VIA The User Interface and Downloadable to a USB Flash Drive
- Modbus Communications with TCP/IP frame format and a shielded female RJ45 connector
- NEMA Type 2 (IEC IP22) enclosure with bottom entry gland plate and lifting lugs
- Suitable for use as Service Equipment
- The controller supplies visual indication of the following: Power Available
 Motor Run Periodic Test Manual Start Deluge Valve Start Remote Automatic Start Remote Manual Start Emergency Start Pump On Demand (Automatic Start) Pump Room Temp. Lockout
- The controller displays visual indication for the following alarm conditions: Control Voltage Not Healthy • Invalid Cut-In • Lock Rotor Current • Loss of Power • Low Ambient Temp. • Low Water Level • Motor Trouble • Phase Reversal
 Overcurrent • Overvoltage • Phase Loss L1 / L2 / L3 • Phase Unbalanced • Pressure Transducer Fault Detected • Pump On Demand • Pump Room Alarm
 Service Required • Undercurrent •
 - Service Required Undercurrent Undervoltage • Check Test Solenoid • Weekly Test Cut-In Reached
- Audible and Visible Indication for Fail To Start.
- DPDT 8A, 250VAC remote alarm contacts are provided for: Power Available
 - Phase Reversal Motor Run
 - Common Pump Room Alarm (Overvoltage / Undervoltage / Phase Unbal-

For Model # Information See Publication SD750-60

For Options and Modifications See Publication OP750-61 ance / Low Pump Room Temp. / High Pump Room Temp)

• Common Motor Trouble (Overcurrent / Fail To Start / Undercurrent / Ground Fault)

- Field Adjustable Timers with Visual Countdown for Minimum Run (Off Delay), Sequential Start (On Delay) and Weekly Test
- Seismíc Certification per IBC 2015, CBC 2016

(Consult Factory for Verification)

Transfer Switch Standard Features – The following are included as standard with each controller:


- Visual indication of the following: Alternate Power Lock Rotor Current • Alternate Power Phase Reversal • Automatic Transfer Switch Trouble
- Audible and Visible indication of: Alternate Power Circuit Breaker OFF or Tripped
 Alternate Power Isolating Switch Tripped/Open
- Transfer Switch test push-button
- Bypass for re-transfer and generator shutdown
- The following adjustable time delays are provided: Momentary Normal Power Outage Override • Emergency Power Available Delay • Transfer Trouble Delay
 • Retransfer to Normal • Generator Cooldown
- Remote Alarm Contacts For: Emergency Isolating Switch Off • Transfer Switch in Normal Position • Transfer Switch in Emergency Position

Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com While every precaution has been take



MARK^{III} Limited Service Electric Fire Pump Controller - Across The Line Starting With Power Transfer Switch



Firetrol, Inc.

3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com

While every precaution has been taken to ensure accuracy and completeness herein, Firetrol, Inc. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications and drawings are subject to change without notice. ©2019 Firetrol, Inc., All Rights Reserved. Option

Option

Option



MARKII Limited Service Electric Fire Pump Controllers - Across The Line Starting With Power Transfer Switch

SPECIAL ENCLOSURES

Description

	I I I I I I I I I I I I I I I I I I I
	Enclosure, NEMA Type 2 (IEC IP22), Painted Steel (Standard)
-E	Enclosure, NEMA Type 4 (IEC IP66), Painted Steel
-F	Enclosure, NEMA Type 4X (IEC IP66), #304 Stainless Steel, Brushed Finish
-FD	Enclosure, NEMA Type 4X (IEC IP66), #316 Stainless Steel, Brushed Finish
-FDB	Enclosure, NEMA Type 4X (IEC IP66), #316 Stainless Steel, Seam Welded, Brushed Finish
-FDP	Enclosure, NEMA Type 4X (IEC IP66), #316 Stainless Steel, Painted Finish
-FXP	Enclosure, NEMA Type 4X (IEC IP66), #304 Stainless Steel, Painted Finish
-G	Enclosure, NEMA Type 12 (IEC IP54), Painted Steel
-T	Enclosure, NEMA Type 3R (IEC IP24), Painted Steel
-U	Enclosure, NEMA Type 3 (IEC IP54), Painted Steel

CIRCUIT BREAKER OPTION* Description

Intermediate Short Circuit Current Rating

			<u> </u>	,						
Code	200-208V	200-208V	220-240V	220-240V	380-415V	380-415V	440-480V	440-480V	550-600V	550-600V
	3-5 HP	7.5-30 HP	3-7.5 HP	10-30 HP	5-10 HP	15-30 HP	5-15 HP	20-30 HP	5-20 HP	25-30 HP
E - Intermediate	N/A	100kA	N/A	100kA	N/A	65kA	N/A	65kA	N/A	25kA
		-								

ANTI-CONDENSATION SPACE HEATERS Description

None	
– J	Space Heater, 120V Externally Powered with Circuit Breaker & Thermostat
-K	Space Heater, 120V Externally Powered with Circuit Breaker & Humidistat
-M	Space Heater, 240V Externally Powered with Circuit Breaker & Thermostat
-N	Space Heater, 240V Externally Powered with Circuit Breaker & Humidistat
-JKP	Space Heater, 120V Externally Powered with Circuit Breaker, Thermostat and Humidistat in Parallel
-MNP	Space Heater, 240V Externally Powered with Circuit Breaker, Thermostat and Humidistat in Parallel

Option

PRESSURE TRANSDUCERS, SOLENOID VALVES, PLUMBING Description

	Wetted Parts including Pressure Sensor and Test Solenoid, 300 PSI (20.4 Bar) Fresh Water
-B1	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar)
	Fresh Water (For Factory Calibration Purposes Only)
-C1	Wetted Parts including Pressure Sensor and Test Solenoid, 300 PSI (20.4 Bar), Sea Water
-D1	Wetted Parts including Pressure Sensor and Test Solenoid, 500 PSI (34.5 Bar), Sea Water
-SP1	Low Suction Pressure Transducer, Fresh Water, 0-300 PSI (20.4 Bar) with Visible Indication and Output Contacts
-SP2	Low Suction Pressure Transducer, Sea Water, 0-300 PSI (20.4 Bar) with Visible Indication
	and Output Contacts
	FOAM PUMP APPLICATIONS
Option	Description
Required	For Foam
-LR1	Low Foam Level External Input, Visible Indications and Alarm Contacts, Additive with
	Provisions for Proof Pressure Switch Connection, With Lockout and Remote Alarm Indication
	For Interlock On (Locked Out)
Required	For Foam
-LK1	Foam Pump Application With Pressure Transducer and Run Test Solenoid Valve

-LK2 Foam Pump Application With Pressure Transducer and Run Test Solenoid Valve, Stainless Steel
--

-LK3 Foam Pump Application Without Pressure Transducer and Run Test Solenoid Valve

Optional For Foam

-DVC Operation, Dump Valve Control

ALARMS

Description

Option	Description
-AC	Extra Alarm Output Contacts, Pump Operating (1 Form A, 1 Form B)
-AM	Alarm Output Contacts, Fail to Start
-AV	Alarm Output Contacts, Low Pump Room Temperature
-AW	Alarm Output Contacts, Reservoir Low
-AY1	Configurable Low Suction Pressure, Visible/Output Contacts with External Digital Input
-BMJ	Extra Alarm Output Contacts, Phase Failure/Phase Reversal
-BY1	Alarm Output Contacts, Overcurrent
-CTSI	Configurable Low Suction Pressure, Visible/Output Contacts with Suction Pressure Transducer
-EH1	Alarm Output Contacts, Main Relief Valve Open
-EK	Alarm Output Contacts, Flow Meter Open
-JR	Visible Indicator, Jockey Pump Operating
-JT	Alarm, Audible/Visible, Jockey Pump Trouble
-KH	Alarm Output Contacts, Common Alarm
-P1	Alarm, Audible/Visible, Built-In 120V Supervisory System (Includes Visible Supervisory Voltage Normal Indication and Audible Pump Operating, Phase Failure and Phase Reversal Indication
-PE	Alarm Putput Contacts, Low System Pressure (Pump on Demand)
-PT	Alarm, Audible/Visible, Built-In 240V Supervisory System (Includes Visible Supervisory Voltage Normal Indication and Audible Pump Operating, Phase Failure and Phase Reversal Indication
	MISCELLANEOUS
Option	Description
-ED2	Normal Source Load Shedding with Adjustable Time Delay to Remove Non-Critical Loads Before Starting
-EL	Series Pumping Operation, High Zone Controller
-EM	Series Pumping Operation, Mid Zone Controller
-EN	Series Pumping Operation, Low Zone Controller
-IEC	Marking, CE with External Wet Parts (Requires NEMA Type 12 (IP54) Enclosure as Minimum)
-MZN	Neutral Lug, Service Entrance, Non-Insulated Bonded to Enclosure
-PK	Terminal Blocks, Extra Remote Start
-PY	Output Contacts, Motor Space Heater, Externally Powered
-S	Tropicalization
-USBX	Data Port, External USB
-Y55	Controller Temperature Rating, 55°C (131°F) Ambient Temperature
-ZPM1	Data Port, RS-485 Modbus RTU

-XCR Export Packaging (Wooden Crating to Conform to IPPC Standards

TRANSFER SWITCH OPTIONS

Description

-ED1 Alternate (Emergency) Source Load Shedding with Adjustable Time Delay to Remove Non-Critical Loads Before Starting



Option

Ontion


3412 Apex Peakway Apex, North Carolina 27502 P +1 919 460 5200 F +1 919 460 5250 www.firetrol.com

While every precaution has been taken to ensure accuracy and completeness herein, Firetrol, Inc. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications and drawings are subject to change without notice. ©2019 Firetrol, Inc., All Rights Reserved.





MARK^{III} Limited Service Electric Fire Pump Controllers - Across The Line Starting With Power Transfer Switch




					RELEASED		-	-	CIR	CIR	11-5-19	
THIRD ANGLE PROJECTION	size A	BY	DATE		REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE	
	DRAWN BY	CIR	11-5-19	Firetrol, Inc.	DIMENSIONS AND SHIPPING WEIGHT	MENSIONS AND SHIPPING WEIGHT TETA/50 WITH FTA9/6		DRAWING NUMBER				
	FINAL	CIR	11-5-19	© Firetrol, Inc. Not for construction.				DWG ECN CHEET				
	APPROVAL drawing and the in				WITH POWER TRANSFER SWITCH echient In strict confidence and may not be retransmitted, published, reproduced, copied or used in any manor, including as the basis for the manufacture of		REV sale of any produ	NO -	ress prior			



FTA750/976

MARK^{III} Limited Service Electric Fire Pump Controllers - Across The Line Starting With Power Transfer Switch



SV	Solenoid Valve
MMB	MarkIII Main Board
XTR	Transformer

* Remove jumper to use this feature

** Contact closes when emergency start is in "ON" position


Drawing for information only. Manufacturer reserves the right to modify this drawing without notice. Contact manufacturer for "As Built" drawing.

$\square \oplus$	SIZE B	BY	DATE		REVISION DESCRIPTION			ECN NO	BY	APP	DATE
		JMW	12-2-19	Firetrol, Inc.	WIRING SCHEMATIC	FTA750 WITH FTA976	DRAWING NUMBER				
THIRD ANGLE PROJECTION		0.000			LIMITED SERVICE FIRE PUMP CONTROLLER			103730-00			CDL
	FINAL APPROVAL	CIR	12-2-19	© Firetrol, Inc. Not for construction. Subject to change without notice.	WITH POWER TRANSFER SWITCH		DWG REV -	NO -		SH	EET 1 OF 1

All rights reserved. The drawing and the Information contained or depicted herein are the sale property of Flerici, Inc. Copies are communicated to the recipient in stitc confidence and may not be retransmitted, published, reproduced, copied or used in any manor, including as the basis for the manufacture or sale of any products, without the express plor written consent of Flerici, Inc.



Power Transfer Switch For Use With MARK^{III} Limited Service Electric Fire Pump Controllers



Drawing for information only. Manufacturer reserves the right to modify this drawing without notice. Contact manufacturer for "As Built" drawing.

		size B	BY	DATE		REVISION DESCRIPTION			ECN NO	BY	APP	DATE
	- T 1L	IDRAWN BY LIMIN I	IM/M/ 1	12/10/19	Firetrol, Inc.	WIRING SCHEMATIC	FTA976	DRAWING NUMBER WS976-61				
THIRD AI PROJEC	стюм ⊢					LIMITED SERVICE CONTROLLER POWER TH	RANSFER SWITCH FOR GEN-SET		1			CDL
		FINAL APPROVAL				AND SECOND UTILITY POWER SOURCE, 220-240V, 3 PHASE		DWG REV -	ECN NO		SH	EET 1 OF 1


All rights reserved. The drawing and the information contained or depicted herein are the sole property of Frietrol, inc. Copies are communicated to the recipient in stilc confidence and may not be retransmitted, published, reproduced, copied or used in any manor, including as the basis for the manufacture or sale of any products, without the express prior written consent of Frietrol, inc.



FTA750

MARKIII Limited Service Electric Fire Pump Controllers - Across The Line Starting

Line Terminals



Notes: 1 - For proper wire sizing, refer to NFPA70 and NEC (USA) or CEC (Canada) or local code. 2 - Controller suitable for service entrance in USA. 3 - For more accurate motor connections refer to motor manufacturer or motor nameplate.

 For more accurate motor connections refer to motor manufacturer or motor nameplate.
 Controller is phase sensitive. Incoming lines must be connected in ABC sequence.
 Field wiring and lug sizes are based on copper conductors only. Do not use aluminium conductors.

	Circuit Brea	aker (CB) Field Wir	ing according to B	ending Space (AW	G or MCM). TERM	INALS L1 - L2 - L3	
Bending Space			3 " (76 mm)				
HP Voltage	5	7.5	10	15	20	25	30
208	1x (10 to 1)	1x (8 to 1)	1x (8 to 1)	1x (6 to 1)	1x (4 to 1)	1x (3 to 1)	1x (2 to 1)
220 to 240	1x (10 to 1)	1x (10 to 1)	1x (8 to 1)	1x (6 to 1)	1x (4 to 1)	1x (4 to 1)	1x (3 to 1)
380 to 416	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (8 to 1)	1x (8 to 1)	1x (6 to 1)	1x (6 to 1)
440 to 480	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (8 to 1)	1x (8 to 1)	1x (6 to 1)
600	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (8 to 1)	1x (8 to 1)


HP Voltage	5	7.5	10	15	20	25	30
208	1x (10)	1x (10)	1x (8 to 2)	1x (6 to 2)	1x (4 to 1)	1x (3 to 1)	1x (2 to 1)
220 to 240	1x (12 to 10)	1x (10)	1x (8 to 2)	1x (6 to 2)	1x (4 to 1)	1x (4 to 1)	1x (3 to 1)
380 to 416	1x (14 to 10)	1x (12 to 10)	1x (8 to 2)	1x (8 to 2)	1x (8 to 2)	1x (6 to 2)	1x (6 to 1)
440 to 480	1x (14 to 10)	1x (14 to 10)	1x (12 to 10)	1x (10)	1x (8 to 2)	1x (8 to 2)	1x (6 to 2)
600	1x (14 to 10)	1x (14 to 10)	1x (14 to 10)	1x (12 to 10)	1x (10)	1x (8 to 2)	1x (8 to 2)

					RELEASED		-	-	CIR	CIR	11-12-19
	SIZE A	BY	DATE		REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE
	DRAWN BY	CIR	11-12-19	Firetrol, Inc.	FIELD CONNECTIONS	FTA750					
THIRD ANGLE	Bround Br					- FC750-70					
	FINAL APPROVAL	CIR	11-12-19	© Firetrol, Inc. Not for construction. Subject to change without notice.	LIMITED SERVICE FIRE PUMP CONTRO	LLER	DWG REV -	ECN -		s⊦	IEET 1 OF 1
Al rights reserved. The	drawing and the in	formation co	ntained or depicted h	erein are the sole property of Firetrol, Inc. Copies are communicated to the re	cipient in strict confidence and may not be retransmitted, published, reproduced, cop	ied or used in any manor, including as the basis for the manufacture or	sale of any produ	cts, without the exp	ress prior v	vritten con	sent of Firetrol, Inc.



FTA750

MARK^{III} Limited Service Electric Fire Pump Controllers - Across The Line Starting




				RELEASED		-	-	CIR	CIR	11-12-19	
SIZE A	BY	DATE		REVISION DESCRIPTION		REV	ECN NO	BY	APP	DATE	
DRAWN BY	CIP	11-12-19	Firetrol, Inc.	FIELD CONNECTIONS	FTA750						
Distant	CIIX	CIR 11-12-19					FC750-71				
FINAL APPROVAL	CIR	11-12-19	© Firetrol, Inc. Not for construction. Subject to change without notice.		ULLER .	DWG REV -	ECN -		SH	IEET 1 OF 1	
	DRAWN BY	DRAWN BY CIR	DRAWN BY CIR 11-12-19	DRAWN BY CIR 11-12-19 FINAL CIR 11-12-19 FINAL CIR 11-12-19	SIZE A BY DATE DRAWN BY CIR 11-12-19 FINAL CIR 11-12-19 © Firstrol, Inc. © Firstrol, Inc.	SIZE A BY DATE REVISION DESCRIPTION DRAWN BY CIR 11-12-19 Firsterol, Inc. FIELD CONNECTIONS FTA750 FINAL CIR 11-12-19 © Firsterol, Inc. Not for construction. IMITED SERVICE FIRE PUMP CONTROLLER	SIZE A BY DATE Revision Description Rev DRAWN BY CIR 11-12-19 Image: Circle of the construction of the constru	SIZE A BY DATE REVISION DESCRIPTION REV ECN NO DRAWN BY CIR 11-12-19 Image: Circle of the construction. FIELD CONNECTIONS FTA750 DRAWING NUMBER FINAL CIR 11-12-19 Image: Circle of the construction. FIELD CONNECTIONS FTA750 Drawing Number FINAL CIR 11-12-19 Image: Circle of the construction. Drawing Number FC750-71 Image: Circle of the circle of the construction. Drawing Number Drawing Number Drawing Number	SIZE A BY DATE DRAWN BY CIR 11-12-19 FINAL CIR FINAL CIR 11-12-19 © Firetrol, Inc. Not or construction. © Firetrol, Inc. Not or construction. © Firetrol, Inc. Not or construction.	SIZE A BY DATE DRAWN BY CIR 11-12-19 FINAL CIR 11-12-19 © Firetol, Inc. Not for construction. FINAL CIR 11-12-19 Offention, Not for construction. FINAL CIR 11-12-19 Offention, Not for construction.	

Al right



Power Transfer Switch For Use With MARK^{III} Limited Service Electric Fire Pump Controllers



Notes Controller is phase sensitive. Incoming lines must be connected in ABC sequence. Field wing and lug sizes are based on copper conductors only. Do not use aluminium conductors.

Bending Space		(Us	(Use Copper Conductors Only)				
HP Voltage	5	7.5	10	15	20	25	30
208	1x (10 to 1)	1x (8 to 1)	1x (8 to 1)	1x (6 to 1)	1x (4 to 1)	1x (3 to 1)	1x (2 to 1)
220 to 240	1x (10 to 1)	1x (10 to 1)	1x (8 to 1)	1x (6 to 1)	1x (4 to 1)	1x (4 to 1)	1x (3 to 1)
380 to 416	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (8 to 1)	1x (8 to 1)	1x (6 to 1)	1x (6 to 1)
440 to 480	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (8 to 1)	1x (8 to 1)	1x (6 to 1)
600	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (10 to 1)	1x (8 to 1)	1x (8 to 1)

